



IntelliGuideTM Vision

User Manual

Part Number 628571 Revision A



Brooks Automation

Information provided within this document is subject to change without notice, and although believed to be accurate, Brooks Automation assumes no responsibility for any errors, omissions, or inaccuracies.

AcuLigner™, Advan Tag™, AutoTeach™, ATR™, AXM™, BiSymmetrik™, CenterSmart™, Crate to Operate™, CrossingConnect™, DARTS™, Enerta™, e-RMA™, e-Spares™, e-Volution™, Falcon™, FIXLOAD™, FrogLeg™, GuardianPro™, Independent Twin Linear Exchange™, InCooler™, InLigner™, Isoport™, ITLX™, Jet™, Jet Engine™, LEAP™, LeapFrog™, LowProfile™, LPT™, M2 Nano™, Marathon 2, Marathon Express, PASIV™, Pathway™, PowerPak™, PowerTools™, PuroMaxx™, QuadraFly™, Radius™, Radiant™, Radiant Express™, Reliance™, Reliance ATR™, RetroEase™, SCARA™, SmartPM™, SMIF-INX™, SMIF-LPT™, SPOTLevel™, The New Pathway to Productivity™, Time Optimized Trajectory™, Time Optimal Trajectory™, Time Optimized Path™, TopCooler™, TopLigner™, VacuTran™, VersaPort™, WaferEngine™, LEAP™, Pathway™, GIO, GSB, Guidance 6600, Guidance 6430, Guidance 6420, Guidance 6410, Guidance 6000, Guidance 3400, Guidance 3300, Guidance 3200, Guidance 2600, Guidance 2400, Guidance 2300, Guidance 2200, Guidance 1400, Guidance 1300, Guidance 1200, Guidance 0200 Slave Amplifier, Guidance 0006, Guidance 0004, Guidance Controller, Guidance Development Environment, GDE, Guidance Development Suite, GDS, Guidance Dispense, Guidance Input and Output Module, Guidance Programming Language, GPL, Guidance Slave Board, Guidance System, Guidance System D4/D6, PreciseFlex™ 300, PreciseFlex™ 400, PreciseFlex™ 3400, PreciseFlex™ 1300, PreciseFlex™ 1400, PreciseFlex™ DD4, PreciseFlex™ DD6, PreciseFlex™ DDR, PreciseFlex™ G5400, PreciseFlex™ G5600, PreciseFlex™ G6400, PreciseFlex™ G6410, PreciseFlex™ G6420, PreciseFlex™ G6430, PreciseFlex™ G6600, PreciseFlex™ GSBP Slave Amp, PreciseFlex™ PFD0, PrecisePlace 100, PrecisePlace 0120, PrecisePlace 0130, PrecisePlace 0140, PrecisePlace 1300, PrecisePlace 1400, PrecisePlace 2300, PrecisePlace 2400, PrecisePower 300, PrecisePower 500, PrecisePower 1000, PrecisePower 2000, PreciseVision, and RIO logos are trademarks of Brooks Automation.

Fusion®, Guardian®, MagnaTran®, Marathon®, Razor®, Spartan®, Vision®, Zaris®, and the Brooks and design logo are registered U.S. trademarks of Brooks Automation.

All other trademarks are properties of their respective owners.

© 2024 Brooks Automation. All rights reserved. The information included in this manual is proprietary information of Brooks Automation, and is provided for the use of Brooks customers only and cannot be used for distribution, reproduction, or sale without the express written permission of Brooks Automation.

This technology is subject to United States export Administration Regulations and authorized to the destination only; diversion contrary to U.S. law is prohibited.

<p>Brooks Automation 15 Elizabeth Drive Chelmsford, MA 01824-2400 Tel: +1 978-262-2400 Fax: +1 978-262-2500</p>	<p>Brooks Automation, PreciseFlex Collaborative Robots 201 Lindbergh Avenue Livermore, CA 94551 Tel: +1-408-224-2838</p>
--	---



Worldwide Headquarters

15 Elizabeth Drive
Chelmsford, MA 01824 U.S.A.

Brooks Automation, PreciseFlex Collaborative Robots

201 Lindbergh Avenue
Livermore, CA 94551 U.S.A

Technical Support

Location	Contact	Website
North America	+1-800-447-5007 (Toll-Free) +1-978-262-2900 (Local) +1-408-224-2838 (PreciseFlex™)	
Europe	support_preciseflex@brooksautomation.com	
Japan	+81 120-255-390 (Toll Free) +81 45-330-9005 (Local)	
China	+86 21-5131-7066	http://www.brooks.com/
Taiwan	+886 080-003-5556 (Toll Free) +886 3-5525258 (Local)	
Korea	1800-5116 (Toll Free)	
Singapore	+65 1-800-4-276657 (Toll Free) +65 6309 0701 (Local)	

General Emails

Division	Email Address
Sales	sales_preciseflex@brooksautomation.com
Technical Support	support_preciseflex@brooksautomation.com
Technical Publications	Technical.Publications@brooksautomation.com



Brooks Automation
15 Elizabeth Drive
Chelmsford, MA
01824-2400
Tel: +1 978-262-2400
Fax: +1 978-262-2500
www.brooks.com

Brooks Locations Worldwide:

Brooks Automation
46702 Bayside Parkway
Fremont, CA 94538
Tel: +1-510-661-5000
Fax: +1-510-661-5166

Brooks Automation
AIM Servicios Administrativos
S de RL de CV
Carretera Huinalá km 2.8
Parque Industrial Las Américas
66640 Apodaca, NL Mexico
Tel: +52 81 8863-6363

**Brooks Automation
(Germany) GmbH**
Ernst-Ruska-Ring 11
07745 Jena, Germany
Tel: +49 3641 4821 100
Fax: +49 3641 4821 4100

**Brooks Automation
(Germany) GmbH**
Daimler-Straße 7
78256 Steißlingen, Germany
Tel: +49-7732-9409-0
Fax: +49-7732-9409-200

Brooks Automation
9601 Dessau Road, Suite 301
Austin, TX 78754
Tel: +1 512-912-2840
Toll-Free: +1 800-367-4887

**Brooks Automation
(Israel) Ltd.**
Mevo Yerach 5
Kiryat-Gat 82000
Israel
Tel: +972 8672 2988
Fax: +972 8672 2966

**Brooks Technology (Shanghai)
Limited**
2nd Floor, No. 72,
887 Zuchongzhi Road
Zhangjiang Hi-Tech
Park Pudong, Shanghai
China 201203
Tel: +86-21-5131-7070
Fax: +86-21-5131-7068

Brooks Japan K.K.
HEADQUARTERS
Nisso Bldg. No 16, 9F
3-8-8 ShinYokohama, Kohoku-ku
Yokohama, Kanagawa 222-0033
Tel: +81-45-477-5570
Fax: +81-45-477-5571

Brooks Japan K.K.
YOKOHAMA TECHNICAL
CENTER
852-1 Kawamuko-cho, Tsuzuki-ku
Yokohama, Kanagawa 224-0044
Tel: +81-45-477-5250
Fax: +81-45-470-6800

Brooks Japan K.K.
KUMAMOTO SERVICE OFFICE
202 Mirai Office II
312-1 Tatsudamachi Yuge
Tatsuda, Kumamoto 861-8002
Tel: +81-96-327-9720
Fax: +81-96-327-9721

Brooks CCS Japan K.K.
CONTAMINATION CONTROL
SOLUTIONS
Nisso Bldg. No 16, 9F
3-8-8 ShinYokohama, Kohoku-ku
Yokohama, Kanagawa 222-0033
Tel: +81-45-477-5570
Fax: +81-45-477-5571

Brooks Automation Ltd.
TAIWANHEADQUARTERS
5F-5, No.32, Tai-Yuen Street
Chu-Pei City
Hsinchu County 302, Taiwan,
R.O.C.
Tel: +886-3-552 5258
Fax (G&A): +886-3-552 5255
Fax (Sales): +886-3-552 5200

Brooks Automation Korea, Inc.
#35 Giheungdanji-Ro 121Beon-
Gil
Giheung-Gu, Yongin-Si
Gyeonggi-Do, 17086
Korea
Tel: +82-31-288-2500
Fax: +82-31-287-2111

**Brooks Automation CCS RS
AG**
Lohstampfstrasse 11
CH-8274 Tagerwilen, Switzerland
Tel: + 41 71-666-72-10
Fax: + 41 71-666-72-11

Brooks Automation Korea
#35 Giheungdanji-Ro 121Beon-
Gil
Giheung-Gu, Yongin-Si
Gyeonggi-Do, 17086
Korea
Tel: +82-31-288-2500
Fax: +82-31-287-2111

Brooks Automation (S) Pte Ltd
51-18-C1 Menara BHL,
57 Jalan Ahmad Shah,
10050, Penang,
Malaysia
Tel: +60 4 3701012
Fax: +60 4 3701015

**Brooks Automation
(Singapore) Pte Ltd**
Blk 5008 Ang Mo Kio Avenue 5
#05-08, Techplace II
Singapore 569874
Tel: +65-6836-3168
Fax: +65-6836-3177

Brooks Automation Ltd.
TAINAN OFFICE
3F., No.11, Nanke 3rd Rd., Xinshi
Dist.
Tainan Science Park
Tainan City 74147, Taiwan
(R.O.C.)
TEL: +886-6-505-0268
FAX: +886-6-505-5228

**Brooks Automation
Precise Collaborative Robotics**
201 Lindbergh Drive
Livermore, CA 94551
Tel: +1-978-262-2400

Revision History

Revision	ECO	Date	Action	Author
A	EC154053	4/18/20204	Released manual at Rev. A to follow standard Brooks technical publication styles. Document Created. Compatibility verified with GDS 5.0.3.1.	M. Ashenfelder

Table of Contents



1. Safety	8
Safety Setup	8
Authorized Personnel Only	8
Explanation of Hazards and Alerts	9
Safety Text	9
Safety Icons	9
Signal Words and Color	9
Alert Example	10
General Safety Considerations	11
Mechanical Hazards	13
Electrical Hazards	14
Ergonomic Hazards	15
Emergency Stop Circuit (E-Stop)	17
Recycling and Hazardous Materials	17
2. Overview	18
IntelliGuide Vision Gripper Functions	18
Features	18
Robot Compatibility	19
IntelliGuide v23	20
IntelliGuide v60	21
Accessories	24
23 N Gripper Fingers	24
ArUco Label Dimensions, Diagrams	25
ArUco Label Kits	28
IntelliGuide Vision Gripper Teach Plate	29
ArUco Calibration Targets	32
Product Numbers	35
3. Operation	36
Connecting to the Robot	36
Enabling Power and Homing the Robot	38
Creating an IntelliGuide Vision Project	40
Creating an IntelliGuide Vision Offset	48
Auto-Teach and Pick and Place	56
4. Vision Toolkit	68
ToolKit Summary	68
Acquisition Tool	69
Fiducial Locator	76
Barcode Reader Tool	78
Special Feature Buttons (located above the property editor)	82
Examples	84
Light Control	84
5. Camera Calibration	86

Stereoscopic Calibration	86
6. Appendices	95
Appendix A: Specifications	96
Appendix B: VSUtilities	97
Installing GDS and Confirming Its Version	97
Changing the IntelliGuide Vision Gripper IP Address	98
Updating IntelliGuide Vision Gripper Software	99

1. Safety

Safety Setup

Brooks uses caution, warning, and danger labels to convey critical information required for the safe and proper operation of the hardware and software. Read and comply with all labels to prevent personal injury and damage to the equipment.

 DANGER Read the Safety Chapter	
<p>Failure to review the <i>Safety</i> chapter and follow the safety warnings can result in serious injury or death.</p> <ul style="list-style-type: none">• All personnel involved with the operation or maintenance of this product must read and understand the information in this safety chapter.• Follow all applicable safety codes of the facility as well as national and international safety codes.• Know the facility safety procedures, safety equipment, and contact information.• Read and understand each procedure before performing it.	

Authorized Personnel Only

This product is intended for use by trained and experienced personnel. Operators must comply with applicable organizational operating procedures, industry standards, and all local, regional, national, and international laws and regulations.

Explanation of Hazards and Alerts

This manual and this product use industry standard hazard alerts to notify the user of personal or equipment safety hazards. Hazard alerts contain safety text, icons, signal words, and colors.

Safety Text

Hazard alert text follows a standard, fixed-order, three-part format.





- Identify the hazard
- State the consequences if the hazard is not avoided
- State how to avoid the hazard.

Safety Icons

- Hazard alerts contain safety icons that graphically identify the hazard.
- The safety icons in this manual conform to ISO 3864 and ANSI Z535 standards.


Signal Words and Color

Signal words inform of the level of hazard.

	<p>Danger indicates a hazardous situation which, if not avoided, will result in serious injury or death.</p> <p>The Danger signal word is white on a red background with an exclamation point inside a yellow triangle with black border.</p>
	<p>Warning indicates a hazardous situation which, if not avoided, could result in serious injury or death.</p> <p>The Warning signal word is black on an orange background with an exclamation point inside a yellow triangle with black border.</p>
	<p>Caution indicates a hazardous situation or unsafe practice which, if not avoided, may result in minor or moderate personal injury.</p> <p>The Caution signal word is black on a yellow background with an exclamation point inside a yellow triangle with black border.</p>
	<p>Notice indicates a situation or unsafe practice which, if not avoided, may result in equipment damage.</p> <p>The Notice signal word is white on blue background with no icon.</p>




Alert Example



The following is an example of a Warning hazard alert.







Number	Description
1.	How to Avoid the Hazard
2.	Source of Hazard and Severity
3.	General Alert Icon
4.	Signal Word
5.	Type of Hazard
6.	Hazard Symbol(s)



General Safety Considerations



 WARNING Software	
<p>Software is not safety rated. Unplanned motion can occur as long as power is supplied to the motors. Maximum torque could be momentarily applied that may cause equipment damage or personal injury.</p> <ul style="list-style-type: none">• Only operate the robot with its covers installed.• Guarantee that safety controller features are in place (for example, an emergency stop button and protective stop).• Regularly test safety components to prove that they function correctly.	 



 WARNING Robot Mounting	
<p>Before applying power, the robot must be mounted on a rigid test stand, secure surface, or system application. Improperly mounted robots can cause excessive vibration and uncontrolled movement that may cause equipment damage or personal injury.</p> <ul style="list-style-type: none">• Always mount the robot on a secure test stand, surface, or system before applying power.	



 WARNING Do Not Use Unauthorized Parts	
<p>Using parts with different inertial properties with the same robot application can cause the robot's performance to decrease and potentially cause unplanned robot motion that could result in serious personal injury.</p> <ul style="list-style-type: none">• Do not use unauthorized parts.• Confirm that the correct robot application is being used.	

 WARNING Magnetic Field Hazard	
<p>This product contains magnetic motors that can be hazardous to implanted medical devices, such as pacemakers, and cause personal harm, severe injury, or death.</p> <ul style="list-style-type: none"> • Maintain a safe working distance of 30 cm from the motor when with an energized robot if you use a cardiac rhythm management device. 	



 CAUTION Unauthorized Service	
<p>Personal injury or damage to equipment may result if this product is operated or serviced by untrained or unauthorized personnel.</p> <ul style="list-style-type: none"> • Only qualified personnel who have received certified training and have the proper job qualifications are allowed to transport, assemble, operate, or maintain the product. 	



 CAUTION Damaged Components	
<p>The use of this product when components or cables appear to be damaged may cause equipment malfunction or personal injury.</p> <ul style="list-style-type: none"> • Do not use this product if components or cables appear to be damaged. • Place the product in a location where it will not get damaged. • Route cables and tubing so that they do not become damaged and do not present a personal safety hazard. 	



 CAUTION Inappropriate Use	
<p>Use of this product in a manner or for purposes other than for what it is intended may cause equipment damage or personal injury.</p> <ul style="list-style-type: none"> • Only use the product for its intended application. • Do not modify this product beyond its original design. • Always operate this product with the covers in place. 	

 CAUTION Seismic Restraint	
<p>The use of this product in an earthquake-prone environment may cause equipment damage or personal injury.</p> <ul style="list-style-type: none">• The user is responsible for determining whether the product is used in an earthquake prone environment and installing the appropriate seismic restraints in accordance with local regulations.	

Mechanical Hazards



 CAUTION Pinch Point	
<p>Moving parts of the product may cause squeezing or compression of fingers or hands resulting in personal injury.</p> <ul style="list-style-type: none">• Do not operate the product without the protective covers in place.	



 WARNING Automatic Movement	
<p>Whenever power is applied to the product, there is the potential for automatic or unplanned movement of the product or its components, which could result in personal injury.</p> <ul style="list-style-type: none">• Follow safe practices for working with energized products per the facility requirements.• Do not rely on the system software or process technology to prevent unexpected product motion.• Do not operate the product without its protective covers in place.• While the collaborative robotics system is designed to be safe around personnel, gravity and other factors may present hazards and should be considered.	



 CAUTION Vibration Hazard	
<p>As with any servo-based device, the robot can enter a vibratory state resulting in mechanical and audible hazards. Vibration indicates a serious problem. Immediately remove power.</p> <ul style="list-style-type: none"> • Before energizing, ensure the robot is bolted to a rigid metal chamber or stand. 	

Electrical Hazards

Refer to the specifications of the *Guidance Controller Quick Start Guide* for the electrical power.



 DANGER Electrical Shock Hazard	
<p>Contact with electrical power can cause personal harm and serious injury.</p> <ul style="list-style-type: none"> • To avoid electrical shock, disconnect the power before troubleshooting the electrical components. • Check the unit's specifications for the actual system power requirements and use appropriate precautions. • Never operate this product without its protection covers on. 	



 WARNING Electrical Burn	
<p>Improper electrical connection or connection to an improper electrical supply can result in electrical burns resulting in equipment damage, serious injury, or death.</p> <ul style="list-style-type: none"> • Always provide the robot with the proper power supply connectors and ground that are compliant with appropriate electrical codes. 	



 WARNING Electrical Fire Hazard	
<p>All energized electrical equipment poses the risk of fire, which may result in severe injury or death. Fires in wiring, fuse boxes, energized electrical equipment, computers, and other electrical sources require a Class C extinguisher.</p> <ul style="list-style-type: none">• Use a fire extinguisher designed for electrical fires (Class C in the US and Class E in Asia).• It is the facility's responsibility to determine if any other fire extinguishers are needed for the system that the robot is in.	

NOTICE	
<p>Improper handling of the power source or connecting devices may cause component damage or equipment fire.</p> <ul style="list-style-type: none">• Connect the system to an appropriate electrical supply.• Turn off the power before servicing the unit.• Turn off the power before disconnecting the cables.	

Ergonomic Hazards



 CAUTION Heavy Lift Hazard	
<p>Failure to take the proper precautions before moving the robot could result in back injury and muscle strain.</p> <ul style="list-style-type: none">• Use a lifting device and cart rated for the weight of the drive or arm.• Only persons certified in operating the lifting device should be moving the product.	

 CAUTION Tipover Hazard	
<p>This product has a high center of gravity which may cause the product to tip over and cause serious injury.</p> <ul style="list-style-type: none">• Always properly restrain the product when moving it.• Never operate the robot unless it is rigidly mounted.	

 CAUTION Trip Hazard	
<p>Cables for power and communication and facilities create trip hazards which may cause serious injury.</p> <ul style="list-style-type: none">• Always route the cables where they are not in the way of traffic.	

Emergency Stop Circuit (E-Stop)

The integrator of the robot must provide an emergency stop switch.

 WARNING Emergency Stop Circuit	
<p>Using this product without an emergency stop circuit may cause personal injury.</p> <ul style="list-style-type: none">• Customer is responsible for integrating an emergency stop circuit into their system.• Do not override or bypass the emergency stop circuit.	

Recycling and Hazardous Materials

Brooks Automation complies with the EU Directive 2002/96/EU Waste Electrical and Electronic Equipment (WEEE).

The end user must responsibly dispose of the product and its components when disposal is required. The initial cost of the equipment does not include cost for disposal. For further information and assistance in disposal, please email Brooks Automation Technical Support at support@preciseflex@brooksautomation.com.

2. Overview

IntelliGuide Vision Gripper Functions

IntelliGuide Vision Grippers include a fully integrated camera-enabled vision system to help guide the robot. Just connect the interface cables, power up the robot, home it, and teach the robot to work on tasks.


The IntelliGuide Vision Gripper's range of functions include decoding ArUco markers and reading 1D and 2D barcodes and other visual identifiers. The Auto-Teach functionality employs a simplified drag-and-drop programming method, called *sequencing*, which allows you to craft a series of instructions and processes for the robot to execute.

Features

The IntelliGuide Vision Gripper has downward- and forward-facing 5 MP cameras – with 150 mm focal distance – as well as integrated lighting controlled via Pulse Width Modulation (PWM) for brightness.

Its functions include:

- Bar code reading, 1D and 2D
- Objection recognition and location
- ArUco marker orientation
- Auto-Teach
- Lighting control




The processing of the images is done on the IntelliGuide Vision Gripper side, and the software that is used to configure and set the vision tools is the Guidance Development Studio (GDS). The vision processing is programmed via GDS over the same Ethernet connection to the base of the robot. By default, the robot IP Address is 192.168.0.1, and the Vision Controller IP Address is 192.168.0.200. Refer to the *Guidance Development Studio* manual for detailed instructions on configuring the vision processing.

Robot Compatibility



PreciseFlex c10 Robot with IntelliGuide v60



PreciseFlex 3400 Robot with IntelliGuide v23

The following table shows which robots the IntelliGuide v23 and v60 are compatible with.

Camera	PreciseFlex 400 *	PreciseFlex 3400 *	PreciseFlex c10
IntelliGuide v23	Compatible	Compatible	Compatible
IntelliGuide v60	Not Compatible	Compatible	Compatible

* Also compatible with these robots on a Collaborative Linear Rail


IntelliGuide v23

The IntelliGuide v23 is designed to handle SBS Plates in both portrait and landscape orientations. Thus it has a wider stroke and lower payload. Similar to the 23 N Servo Gripper, it can apply 23 Newtons of force, and it requires homing when the robot is powered off and back on.


The IntelliGuide v23 features include:

- 23 N gripping force
- 60 mm stroke
- (Picks SBS plates in portrait and landscape modes)
- 1.0 kg payload (may be limited by robot payload)


NOTE: All dimensions are in millimeters.



IntelliGuide v23, Front View



IntelliGuide v23, Side View



IntelliGuide v23, Top View

IntelliGuide v60

The IntelliGuide v60 is designed to handle heavier payloads and can only grab SBS Plates in one orientation, either portrait or landscape. Thus it has a shorter stroke and higher payload. It can apply


60 Newtons of force. With an absolute encoder, it does not require homing when the robot is powered off and back on.

The 60 N gripper can only pick up plates in one orientation while the 23 N gripper can pick up in two orientations without changing fingers due to its longer stroke.


The IntelliGuide v60 features include:

- 60 N gripping force
- 40 mm stroke
- (Picks SBS plates in either portrait or landscape modes)
- 3.0 kg payload (may be limited by robot payload)


NOTE: All dimensions are in millimeters.



IntelliGuide v60, Front View.



IntelliGuide v60, Side View.




IntelliGuide v60, Top View.


Accessories

23 N Gripper Fingers

NOTE: All dimensions are in millimeters.



23 N Gripper Fingers for Microtiter Plates, Side



23 N Gripper Fingers for Microtiter Plates, Front


ArUco Label Dimensions, Diagrams

An ArUco is a square graphic data matrix, similar to a QR code (see images below). A target sticker utilizes a left and right ArUco to help align the IntelliGuide Vision Gripper camera by:

- calculating the center of each ArUco
- calculating the exact distance between the two ArUco center points (ArUco Distance relative to the camera)
- calculating the line between the two ArUco center points (ArUco Rotation relative to the camera).


These calculations help determine the camera's relative location -- such as distance and level -- in the work-envelope space.

NOTE: In the ArUco examples below, distance is shown in millimeters.




Label, Front Narrow, Teach Plate

- Distance Center-to-Center of ArUco Square: 51 mm (displayed as "xx 51 mm xx" in example above)
- ArUco Size: 9x9 mm
- Part # 500372




Label, Top Wide, Vision, Teach Plate

- Distance Center-to-Center of ArUco Square: 63 mm (displayed as "xx 63 mm xx" in example above)
- ArUco size: 9x9 mm
- Part #500373




Label, Front Wide, Vision, Teach Plate

- Distance Center-to-Center of ArUco Square: 63 mm (displayed as "xx 63 mm xx" in example above)
- ArUco Size: 9x9 mm
- Part #500374




Label, Top Narrow, Vision Teach Plate

- Distance Center-to-Center of ArUco Square: 51 mm (displayed as "xx 51 mm xx" in example above)
- ArUco Size: 9x9 mm
- Part #500375




Label, Medium Wide, ArUco

- Distance Center-to-Center of ArUco Square: 93 (displayed as "xx 93 mm xx" in example above)
- ArUco Size: 18x18
- Part #620523




Label, Medium Narrow, ArUco, IntelliGuide

- Distance Center-to-Center of ArUco Square: 68 mm (displayed as "xx 68 mm xx" in example above)
- ArUco Size: 18x18 mm
- Part #620525



Label, Large Wide, ArUco, IntelliGuide

- Distance Center-to-Center of ArUco Square: 163 mm (displayed as "xx 163 mm xx" in example above)
- ArUco Size: 23x23 mm
- Part #620526



620527 - Label, Large Narrow, ArUco, IntelliGuide

- Distance Center-to-Center of ArUco Square: 113 mm (displayed as "xx 113 mm xx" in example above)
- ArUco Size: 23x23 mm
- Part #620527

ArUco Label Kits

Use ArUco label kits to get started with Auto-Teach.

PART NUMBER	KIT	QUANTITY IN EACH
620515-1	ArUco labels for SBS Plates	
500372	Teach Plate Label, Front Narrow	1
500373	Teach Plate Label, Top Wide	1
500374	Teach Plate Label, Front Wide	1
500375	Teach Plate Label, Top Narrow	1

PART NUMBER	KIT	QUANTITY IN EACH
620522-1	ArUco labels, Small	
500373	Teach Plate Label, Small Wide	12
500375	Teach Plate Label, Small Narrow	12


PART NUMBER	KIT	QUANTITY IN EACH
620528-1	ArUco labels, Medium	
620523	Teach Plate Label, Medium Wide	12
620525	Teach Plate Label, Medium Narrow	12

PART NUMBER	KIT	QUANTITY IN EACH
620529-1	ArUco labels, Large	
620526	Teach Plate Label, Large Wide	12
620527	Teach Plate Label, Large Narrow	12


IntelliGuide Vision Gripper Teach Plate

The IntelliGuide Vision Gripper Teach Plate is used for teaching an entire SBS Plate Hotel via Vision. The eight (8) protruding M5 rolling ball tip set screws are designed to lock into the notches in the gripper fingers to provide a reliable grip for teaching hotel shelves where the plate cannot slip in the figures, which would create inaccuracies.


NOTE: All dimensions are in millimeters.




IntelliGuide Vision Gripper Teach Plate Dimensions



Recessed Holes on SBS Plate Gripper Fingers for Aligning w/Rolling Ball Tip Set Screws




Ball Tip Set Screws in Recessed Holes on SBS Plate Gripper Fingers



Teach Plate with SBS Plate Fingers


ArUco Calibration Targets

The 8.5x11 with 10 mm Calibration Target below is for use with Arm Reach under 700 mm.




ArUco Calibration Target - 8.5x11 with 10.5 mm

The 11x17 with 12.5 mm Calibration Target below is for use with Arm Reach over 700 mm and with focal distances of 150 mm or less. (Factory default focal distance is 150 mm)



ArUco Calibration Target - 11X17 with 13 mm

The 11" x 17" with 22 mm Calibration Target below is for use with Arm Reach over 700 mm and with custom focal distances over 150 mm.



ArUco Calibration Target - 11x 17 with 22 mm


Product Numbers

Product Number	Product
PF0V-MA-00001	IntelliGuide v23
PF3V-MA-00001	IntelliGuide v60
620515-1	Kit, ArUco labels, SBS Plates
620522-1	Kit, ArUco labels, small
620528-1	Kit, ArUco labels, medium
620529-1	Kit, ArUco labels, large
620521-1	Teach Plate, with ArUco markers
620530-1	ArUco Calibration Target, 8.5x11, 10.5 mm
620531-1	ArUco Calibration Target, 11X17, 13 mm, small
620532-1	ArUco Calibration Target, 11x 17, 22 mm, large
397673	Plate Fingers for IntelliGuide v23

3. Operation

Connecting to the Robot

Plug in all required peripheral devices and interface connectors, such as the power cable (number 5 below) and the Ethernet connector (number 7 below) in this Facilities Panel diagram.





Facilities Panel, Key

Annotation	Name	Description
1	9 Pin D Sub Connector	RS-232 Serial Port, 24 VDC, for optional RS-232 devices. The ground can be used for the optional teach pendant.

Annotation	Name	Description
2	E-Stop Connector	E-Stop and Cell Interlock Signals. Required.
3	25 Pin D Sub Connector	GIO Module for connecting general digital inputs and outputs. See the robot manual for details.
4	Pneumatic Ports	For attaching air lines for optional pneumatic gripper.
5	Power Entry Module	For IEC plug. Contains dual fuse drawer.
6	Power Switch	Lighted power switch. Enable this last after all interfaces and power connectors are plugged in.
7	Ethernet Connector	Ethernet to computer cable. Required for communicating via the interface.
8	Status Light	A blinking light indicates the normal state, a solid light indicates an error, and no light indicate a possible issue with the controller.

To connect the computer to the robot and display the IntelliGuide Vision Gripper interface, perform the following steps.

Step	Action
1.	<p>Use an Ethernet cable to connect the computer to the Ethernet port of the robot.</p>  <p>NOTE: For more information about the Guidance Development Studio (GDS), refer to the GDE/GDS user manual.</p>





Step	Action
2.	<p>Start the Guidance Development Studio (GDS), and enter the IP addresses to establish communication with the robot and the remote vision server. The default IP address for the robot is 192.168.0.1. The default IP address for the vision server is 192.168.0.200. Click Connect.</p> <p>NOTE: The robot and the computer with installed GDS must be on the same network.</p> 

Enabling Power and Homing the Robot

Homing a robot requires initializing or resetting it to a known reference point within its workspace, often termed the "home position" or "home location." This process involves moving the robot to a predefined starting position, aligning its end-effector with a specific target, and calibrating its sensors and actuators for accurate movement and positioning, whether by manual controls or software commands.

For this manual, we assume that the factory calibration is performed. In this case, homing the robot means only clicking the **Home** button so the home offsets are applied if the user power cycled the robot.

Perform the following steps to enable power and home the robot.


Step	Action
1.	<p>With the robot and laptop connected and GDS running, in GDS, open the Controller drop-down menu and select Virtual Pendant.</p> 
2.	<p>The Virtual Pendant displays. Click Enable, which enables the motor power. After the power is enabled, click Home to home the robot.</p>  <div data-bbox="305 1528 1386 1642" style="background-color: yellow; border: 1px solid black; padding: 5px;"> <p> CAUTION Robot Movement</p> </div> <div data-bbox="305 1642 1130 1843" style="border: 1px solid black; padding: 10px;"> <p>Depending on the robot's type, it may move during homing. Be aware of the robot's movements, and ensure nothing is obstructing the robot's motion during the homing process.</p> </div> <div data-bbox="1146 1654 1338 1822" style="text-align: right;">  </div>





Creating an IntelliGuide Vision Project




This section will take you through the steps of creating an IntelliGuide vision project and process. The procedure involves acquiring images and analyzing ArUco data, if it is present in the image, to test vision processes before integrating them into a robot's operational workflow. It's a preparatory step to ensure the vision system functions correctly before deploying it in practical robot operations.




In most cases, only a single vision process is executed in order to perform the complete machine vision task. Typically, this vision process will take a picture and then utilize vision tools to locate a part and validate some key features or dimension. However, if a more complex machine vision operation is required, you can execute multiple vision processes, which can be stored in a *Vision Project*.



To create an IntelliGuide vision project, perform the following procedure.


Step	Action
1.	<p>In GDS top menu, open the Vision drop-down menu and select Vision Project to display the Vision Project window.</p>  <p>The screenshot shows the GDS software interface. The 'Vision' menu is open, and 'Vision Project' is highlighted with a red box. Other menu items include 'Show Vision Toolbar', 'Cameras', 'Tool Properties', 'Camera Configuration', 'Vision License', 'Classifier Models', 'Pixel Calibration', 'Clear Pixel Calibration', 'Arm Mounted Camera', 'Fixed Mounted Camera', 'Upward Facing Camera', and 'Stereoscopic Arm Camera'. The background shows the GDS main window with a toolbar and a project list.</p>
2.	<p>The Vision Project section will contain three windows:</p> <ul style="list-style-type: none">• Process Manager: Build and run processes.• Vision Toolbox: Select from various Vision Tools.• Vision Tools: User specific vision tools for your processes.


Step	Action
3.	<p>In the Process Manager window, click Create a new process .</p>  <p>The screenshot shows the 'Process Manager' window with a toolbar at the top. A red arrow points to the 'Create a new process' icon, which is a document with a plus sign.</p>
4.	<p>In the Enter Name For: popup window, enter a process name, any name you want, and click Accept.</p>  <p>The screenshot shows the 'Enter Name for:' popup window. The text field contains 'VisionProcess'. The 'Accept' button is highlighted.</p>
5.	<p>The process name will then display in the Process Manager window.</p>  <p>The screenshot shows the 'Process Manager' window with 'VisionProcess' listed in the main area.</p>
6.	<p>In the Vision Toolbox window, double-click the Acquire vision tool to create a new vision tool. In the popup window enter any name and click Accept. This tool will enable the camera to take a snapshot of whatever it sees and display this image.</p>  <p>The screenshot shows the 'Vision Toolbox' window with the 'Acquire' tool selected. A red arrow points to the 'Acquire' tool. An 'Enter Name for:' popup window is open, showing 'Acquire_image' in the text field.</p>


Step	Action
7.	<p>In the Vision Toolbox window, double-click Fiducial Locator, and enter any name into the popup window. A fiducial locator detects a marker in the camera's field of view. It is used as a point of reference to help determine location. Click Accept when you are finished.</p> 
8.	<p>Drag the two newly created vision tools into the Process Manager window.</p> 
9.	<p>In the Process Manager window, click Run the selected process to test the image acquisition and the ArUco locator tools. This will execute the vision process by acquiring a new image and applying the associated vision tools. The process will run through once.</p> <p>NOTE: The tools will run sequentially in the order they are listed, from top to bottom.</p> 

Step	Action
10.	<p>You can also select Run the selected process in continuous mode, which will loop the process until you stop it.</p> 
11.	<p>Open the Vision drop-down menu and select Cameras to display the acquired image and the processed results.</p> <p>NOTE: The acquired image is a snapshot the camera took of what it sees.</p> 
12.	<p>The image displays. In this example, the ArUco displays what the camera sees. The results, camera coordinates, and robot coordinates, are displayed in the window below the image.</p> 

Step	Action
<p>13.</p>	<p>To adjust the vision tool properties, open the Vision drop-down menu and select Tool Properties.</p>  <p>The screenshot shows the software's main window with the 'Vision' menu open. The 'Tool Properties' option is highlighted with a red box. Other menu items include 'Show Vision Toolbar', 'Vision Project', 'Cameras', 'Camera Configuration', 'Vision License', 'Classifier Models', 'Pixel Calibration', 'Clear Pixel Calibration', 'Arm Mounted Camera', 'Fixed Mounted Camera', 'Upward Facing Camera', and 'Stereoscopic Arm Camera'.</p>
<p>14.</p>	<p>On the right side of the screen, the Tool Properties window will display the properties of the acquired image.</p>  <p>The screenshot shows the 'Tool Properties' window with a red border. It contains several sections: 'Identity' (Camera Number: 1, Name: Acquire_image), 'Advanced Operation' (Acquire Extension: PNG, Acquire Max Save Images: 100, Acquire Mode: Normal Acquire, Acquire Path, Acquire Prefix: demoimage, Active Layer: Monochrome, Jpeg Quality: 90), and 'Video Properties' (Backlight Compensation: 1, Brightness: 8, Contrast: 8, Exposure: 5, Gain: 3, Gamma: 10, Hue: 0, Saturation: 7, Sharpness: 0, White Balance: 2800). The background shows a camera display with a grayscale image of a robot gripper and a 'Vision Results' table.</p>

Step	Action																																														
15.	<p>You may need to adjust the acquisition parameters in the Tool Properties window based on the environment where the robot is located. The default parameters are only used for reference and a starting point when setting up the vision application.. The default settings for the Image Acquisition tool are shown below.</p>  <table border="1" data-bbox="324 420 779 1270"><thead><tr><th>Property</th><th>Value</th></tr></thead><tbody><tr><td colspan="2">Identity</td></tr><tr><td>Camera Number</td><td>1</td></tr><tr><td>Name</td><td>Acquire_image</td></tr><tr><td colspan="2">Advanced Operation</td></tr><tr><td>Acquire Extension</td><td>PNG</td></tr><tr><td>Acquire Max Save Images</td><td>100</td></tr><tr><td>Acquire Mode</td><td>Normal Acquire</td></tr><tr><td>Acquire Path</td><td></td></tr><tr><td>Acquire Prefix</td><td>demoimage</td></tr><tr><td>Active Layer</td><td>Monochrome</td></tr><tr><td>Jpeg Quality</td><td>90</td></tr><tr><td colspan="2">Video Properties</td></tr><tr><td>Backlight Compensation</td><td>1</td></tr><tr><td>Brightness</td><td>8</td></tr><tr><td>Contrast</td><td>8</td></tr><tr><td>Exposure</td><td>5</td></tr><tr><td>Gain</td><td>3</td></tr><tr><td>Gamma</td><td>10</td></tr><tr><td>Hue</td><td>0</td></tr><tr><td>Saturation</td><td>7</td></tr><tr><td>Sharpness</td><td>0</td></tr><tr><td>White Balance</td><td>2800</td></tr></tbody></table>	Property	Value	Identity		Camera Number	1	Name	Acquire_image	Advanced Operation		Acquire Extension	PNG	Acquire Max Save Images	100	Acquire Mode	Normal Acquire	Acquire Path		Acquire Prefix	demoimage	Active Layer	Monochrome	Jpeg Quality	90	Video Properties		Backlight Compensation	1	Brightness	8	Contrast	8	Exposure	5	Gain	3	Gamma	10	Hue	0	Saturation	7	Sharpness	0	White Balance	2800
Property	Value																																														
Identity																																															
Camera Number	1																																														
Name	Acquire_image																																														
Advanced Operation																																															
Acquire Extension	PNG																																														
Acquire Max Save Images	100																																														
Acquire Mode	Normal Acquire																																														
Acquire Path																																															
Acquire Prefix	demoimage																																														
Active Layer	Monochrome																																														
Jpeg Quality	90																																														
Video Properties																																															
Backlight Compensation	1																																														
Brightness	8																																														
Contrast	8																																														
Exposure	5																																														
Gain	3																																														
Gamma	10																																														
Hue	0																																														
Saturation	7																																														
Sharpness	0																																														
White Balance	2800																																														



Step	Action																																										
16.	<p>Use the correct ArUco Dictionary for setting up the Fiducial Locator tool. For each teach plate that Brooks supplies, a 6x6 ArUco dictionary is used.</p> <p>NOTE: If you change the dictionary, make sure to select the correct one. There are few different ArUco dictionaries, including:</p> <ul style="list-style-type: none"> • 4x4 - contains 50 ArUco markers • 5x5 - contains 100 ArUco markers • 6x6 - contains 250 ArUco markers • 7x7 - contains 1000 ArUco markers  <p>The screenshot shows the 'Tool Properties' dialog box with the following settings:</p> <table border="1"> <thead> <tr> <th>Property</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td colspan="2">Identity</td> </tr> <tr> <td>Camera Number</td> <td>1</td> </tr> <tr> <td>Name</td> <td>Aruco_locator</td> </tr> <tr> <td colspan="2">Placement / Size</td> </tr> <tr> <td>Height</td> <td>1056.397</td> </tr> <tr> <td>Width</td> <td>1508.860</td> </tr> <tr> <td>X Position</td> <td>1270.070</td> </tr> <tr> <td>Y Position</td> <td>1175.199</td> </tr> <tr> <td colspan="2">Operation</td> </tr> <tr> <td>Adaptive Threshold</td> <td>7</td> </tr> <tr> <td>Corner Max Iterations</td> <td>30</td> </tr> <tr> <td>Corner Min Accuracy</td> <td>0.100</td> </tr> <tr> <td>Corner Refinement</td> <td>Sub-Pixel</td> </tr> <tr> <td>Corner Window Size</td> <td>5</td> </tr> <tr> <td>Dictionary</td> <td>6x6 (250)</td> </tr> <tr> <td>Relative Tool</td> <td>No Tool</td> </tr> <tr> <td colspan="2">Results Settings</td> </tr> <tr> <td>Result Color</td> <td>Gold</td> </tr> <tr> <td>Result Scale</td> <td>1.000</td> </tr> <tr> <td>Show Results</td> <td>Point</td> </tr> </tbody> </table>	Property	Value	Identity		Camera Number	1	Name	Aruco_locator	Placement / Size		Height	1056.397	Width	1508.860	X Position	1270.070	Y Position	1175.199	Operation		Adaptive Threshold	7	Corner Max Iterations	30	Corner Min Accuracy	0.100	Corner Refinement	Sub-Pixel	Corner Window Size	5	Dictionary	6x6 (250)	Relative Tool	No Tool	Results Settings		Result Color	Gold	Result Scale	1.000	Show Results	Point
Property	Value																																										
Identity																																											
Camera Number	1																																										
Name	Aruco_locator																																										
Placement / Size																																											
Height	1056.397																																										
Width	1508.860																																										
X Position	1270.070																																										
Y Position	1175.199																																										
Operation																																											
Adaptive Threshold	7																																										
Corner Max Iterations	30																																										
Corner Min Accuracy	0.100																																										
Corner Refinement	Sub-Pixel																																										
Corner Window Size	5																																										
Dictionary	6x6 (250)																																										
Relative Tool	No Tool																																										
Results Settings																																											
Result Color	Gold																																										
Result Scale	1.000																																										
Show Results	Point																																										




Step	Action												
17.	<p>If the Acquire and Fiducial tools are configured correctly, the image should look clear and the results from the tool will be displayed when the user selects the vision tools.</p>  <p>The screenshot displays the Vision Project software interface. On the left, the 'Process Manager' shows a 'VisionProcess' with 'Acquire_image (652 ms)' and 'Aruco_locator (46 ms)'. Below it, the 'Vision Toolbox' includes 'General', 'Acquire', 'Classifier', 'Image Processing', 'Light Control', and 'Sharpness Detector'. The 'Vision Tools' section shows 'Acquire' (with 'Acquire_image') and 'Fiducial Locator' (with 'Aruco_locator' selected). The main 'Camera Display' window shows a grayscale image of an Aruco marker with a yellow square at its center. Below the image, the mouse position is '1126.99, 902.24 mm' and 'MM/Pixel: 1.000'. At the bottom, the 'Vision Results' table shows 1 result in 46 ms.</p> <table border="1" data-bbox="673 892 1218 1039"> <thead> <tr> <th>Corner 2 X</th> <th>Corner 2 Y</th> <th>Corner 3 X</th> <th>Corner 3 Y</th> <th>Corner 4 X</th> <th>Corner 4 Y</th> </tr> </thead> <tbody> <tr> <td>392.407</td> <td>1185.114</td> <td>1397.053</td> <td>957.182</td> <td>1164.540</td> <td>955.261</td> </tr> </tbody> </table>	Corner 2 X	Corner 2 Y	Corner 3 X	Corner 3 Y	Corner 4 X	Corner 4 Y	392.407	1185.114	1397.053	957.182	1164.540	955.261
Corner 2 X	Corner 2 Y	Corner 3 X	Corner 3 Y	Corner 4 X	Corner 4 Y								
392.407	1185.114	1397.053	957.182	1164.540	955.261								




Creating an IntelliGuide Vision Offset




Processing images identifies fiducial markers and calculates a midpoint. However, this alone isn't enough for the robot. A vision offset guides the robot's movement from the midpoint to pick up the object, ensuring accurate interaction.




Perform the following procedure to create an IntelliGuide vision offset.



Step	Action
1.	<p>In the GPL Project window, click Add new project to create a project.</p>  <p>The screenshot shows the 'GPL Projects' window with a menu bar (File, Edit, Controller, Vision, Window) and a toolbar. A red box highlights the 'Add a new project' button in the toolbar, and a mouse cursor is pointing at it. The window title is '192.168.8.13' and it shows 'Memory 31% of 11.60 MB Used'.</p>
2.	<p>In the Create New Project popup window, open the Project Type drop-down menu and select Sequence Project.</p>  <p>The screenshot shows the 'Create New Project' dialog box over the 'GPL Projects' window. The 'Project Type' dropdown menu is open, showing 'Gpl Project' and 'Sequence Project'. A red box highlights the 'Sequence Project' option, and a red arrow points to it from the 'Project Type' label. The dialog also shows 'Source Location' (Memory (Controller)), 'Project Name', and 'Flash 19% of 12.58 MB Used'.</p>



Step	Action
3.	<p>Add a Project Name for the project, any name, and click Accept.</p> 
4.	<p>In the Auto_teach window, double-click on GModule.gpo to add and edit location.</p> 
5.	<p>In the GModule.gpo window, select Locations from the list of variable types, and click Add new variable to add a location.</p> 



Step	Action																																			
6.	<p>In the Create New Variable popup window, add a Variable Name for the location and click Accept.</p> 																																			
7.	<p>Repeat the preceding steps to add a few more locations.</p>  <table border="1" data-bbox="495 808 1258 966"> <thead> <tr> <th>Name</th> <th>Type</th> <th>Location</th> <th>Config</th> <th>Ref Frame</th> <th>Z Clearance</th> <th>Z World</th> </tr> </thead> <tbody> <tr> <td>offset_loc</td> <td>Cartesian</td> <td>90.956 26.921 52.483 90.000 1.181 -90.000</td> <td>Unchanged</td> <td></td> <td>1E+32</td> <td><input type="checkbox"/></td> </tr> <tr> <td>picture_loc</td> <td>Cartesian</td> <td>550.991 -104.507 197.039 1.895 90.000 -180.000</td> <td>Unchanged</td> <td></td> <td>1E+32</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>place</td> <td>Cartesian</td> <td>491.347 -252.799 197.039 -1.020 90.000 180.000</td> <td>Unchanged</td> <td></td> <td>1E+32</td> <td><input type="checkbox"/></td> </tr> <tr> <td>result_loc</td> <td>Cartesian</td> <td>0.000 0.000 0.000 0.000 0.000 0.000</td> <td>Unchanged</td> <td></td> <td>1E+32</td> <td><input type="checkbox"/></td> </tr> </tbody> </table>	Name	Type	Location	Config	Ref Frame	Z Clearance	Z World	offset_loc	Cartesian	90.956 26.921 52.483 90.000 1.181 -90.000	Unchanged		1E+32	<input type="checkbox"/>	picture_loc	Cartesian	550.991 -104.507 197.039 1.895 90.000 -180.000	Unchanged		1E+32	<input checked="" type="checkbox"/>	place	Cartesian	491.347 -252.799 197.039 -1.020 90.000 180.000	Unchanged		1E+32	<input type="checkbox"/>	result_loc	Cartesian	0.000 0.000 0.000 0.000 0.000 0.000	Unchanged		1E+32	<input type="checkbox"/>
Name	Type	Location	Config	Ref Frame	Z Clearance	Z World																														
offset_loc	Cartesian	90.956 26.921 52.483 90.000 1.181 -90.000	Unchanged		1E+32	<input type="checkbox"/>																														
picture_loc	Cartesian	550.991 -104.507 197.039 1.895 90.000 -180.000	Unchanged		1E+32	<input checked="" type="checkbox"/>																														
place	Cartesian	491.347 -252.799 197.039 -1.020 90.000 180.000	Unchanged		1E+32	<input type="checkbox"/>																														
result_loc	Cartesian	0.000 0.000 0.000 0.000 0.000 0.000	Unchanged		1E+32	<input type="checkbox"/>																														
8.	<p>To access the Vision offset wizard, click the Teach vision pick offset button in the GModule.gpo window.</p> 																																			



Step	Action
9.	<p>In the Select a camera popup window, select the camera number (for this example, you will use camera 1, the front camera), and click Accept.</p> 
10.	<p>In the next window, click the Initialize button to load the required system files and initialize the vision system, then click Next.</p> 
11.	<p>In the Select a Vision Tool window, load and select the related Vision Project, Vision Process, and Vision Tool. Click Next when you are finished.</p> <p>NOTE: Be specific. If you have multiple vision projects, the chosen tools are crucial for the offset's accuracy. In this case, for example, the ArUco locator tool is required to detect the offset effectively.</p> 

Step	Action
<p>12.</p>	<p>Make selections on the Select Desired Options page.</p> 
<p>13.</p>	<p>In the Mode of Operation section of the options page, select the option for Teach New Offset or Test Current Offset.</p> 
<p>14.</p>	<p>In the General Parameters section, define the safe approach height.</p> <p>NOTE: Safe approach height refers to the distance between the robot's gripper and the target object, ensuring that the gripper's fingers do not collide with the target during image acquisition. It allows the robot to have clear visibility of the target while avoiding any potential collisions during the picking process.</p> 

Step	Action
15.	<p>In the Calibration Type, specify the Fiducial mode, single or double. This example shows double ArUco detection. Define the ArUco numbers, the distance between the fiducial markers, and the optimal distance to the target. Define the servo open position, how much the gripper fingers should open in order for the gripper to safely go around the target. When you are finished, click Next.</p> 
16.	<p>In the Teach the Picture Position window, click Record to save the current location that will be used to take a picture of the teach plate with the two ArUcos labels. The location should be recorded so the two ArUcos are in the field of view, and the distance matches the originally configured optimal distance of 150 mm. Click Locate to take the image and confirm that the location is appropriate for the operation. Click Next when you are finished.</p> 

Step	Action
17.	<p>In the Locate Target window, click Locate. This is an automated operation, and the robot will enable power and move so that it can take stereo images of the target. Click Next when you complete the operation.</p> 
18.	<p>In the Align Robot to the Pick Position window, free the joints by clicking Free Joints and aligning the end effector with the target to be picked. Click Record when the end effector is perfectly aligned. This is critical step for setting up a proper offset. Click Next when you are finished.</p> 



Step	Action
<p>19.</p>	<p>In the Approach the Target Position window, click Approach to approach the target. The robot will move and approach the target. Click Next when you are finished.</p> 
<p>20.</p>	<p>In the Move to Picture Position window, click the Move button to move to the picture location. At this stage, you can use Locate to ensure the target can be located and the label is in the camera's field of view. Click Next after you complete the motion.</p> 



Step	Action																												
21.	<p>After you click Next, the Process Complete window will display.</p>  <p>The process has been successfully completed. The calculated offset is:</p> <table border="1" data-bbox="495 472 1177 520"> <thead> <tr> <th>X</th> <th>Y</th> <th>Z</th> <th>Yaw</th> <th>Pitch</th> <th>Roll</th> </tr> </thead> <tbody> <tr> <td>90.956</td> <td>26.921</td> <td>52.483</td> <td>90.000</td> <td>1.181</td> <td>-90.000</td> </tr> </tbody> </table>	X	Y	Z	Yaw	Pitch	Roll	90.956	26.921	52.483	90.000	1.181	-90.000																
X	Y	Z	Yaw	Pitch	Roll																								
90.956	26.921	52.483	90.000	1.181	-90.000																								
22.	<p>Confirm that the offset was recorded in the selected location variable in the GModule.gpo window.</p>  <table border="1" data-bbox="386 892 1096 997"> <thead> <tr> <th>Name</th> <th>Type</th> <th>Location</th> <th>Config</th> <th>Ref Frame</th> <th>Z Clearance</th> <th>Z World</th> </tr> </thead> <tbody> <tr> <td colspan="7">Item Count: 2</td> </tr> <tr> <td>offset_loc</td> <td>Cartesian</td> <td>90.956 26.921 52.483 90.000 1.181 -90.000</td> <td>Unchanged</td> <td></td> <td>1E+32</td> <td><input checked="" type="checkbox"/></td> </tr> <tr> <td>result_loc</td> <td>Cartesian</td> <td>0.000 0.000 0.000 0.000 0.000 0.000</td> <td>Unchanged</td> <td></td> <td>1E+32</td> <td><input type="checkbox"/></td> </tr> </tbody> </table>	Name	Type	Location	Config	Ref Frame	Z Clearance	Z World	Item Count: 2							offset_loc	Cartesian	90.956 26.921 52.483 90.000 1.181 -90.000	Unchanged		1E+32	<input checked="" type="checkbox"/>	result_loc	Cartesian	0.000 0.000 0.000 0.000 0.000 0.000	Unchanged		1E+32	<input type="checkbox"/>
Name	Type	Location	Config	Ref Frame	Z Clearance	Z World																							
Item Count: 2																													
offset_loc	Cartesian	90.956 26.921 52.483 90.000 1.181 -90.000	Unchanged		1E+32	<input checked="" type="checkbox"/>																							
result_loc	Cartesian	0.000 0.000 0.000 0.000 0.000 0.000	Unchanged		1E+32	<input type="checkbox"/>																							



Auto-Teach and Pick and Place




In the Auto-Teach process, you teach the robot to locate an object. In the Pick and Place process, you teach the robot to grab the object it located and do something with it. You do this with a simplified form of programming, where you drag and drop pre-programmed commands into a sequence of steps.




Perform the following procedure.

Step	Action
1.	<p>Double-click on the sequence project you constructed in Creating an IntelliGuide Vision Offset.</p> 
2.	<p>After selecting the sequence project, the edit panel will display the Available States. From here, you can add statements to the project.</p> 




Step	Action
3.	<p>If the Statement Browser window is not displaying, open the Controller drop-down menu and select Statement Browser to enable it.</p>  <p>The screenshot shows a software menu with the following items: Show Controller Toolbar (checked), Find & Replace, Find Results, Output, Compilation Results, GPL Projects, Threads, Console, Watch Window, Breakpoints, Virtual Pendant, I/O, File Management, Gpl Object Browser, Dialog Manager, Statement Browser (highlighted with a red box), Custom Statements, and GDS License.</p>
4.	<p>When the default sequence is created, it comes pre-configured with three default states:</p> <ul style="list-style-type: none"> • OnInitialize: the initial state where the robot needs to initialize • OnRun: the secondary state where the robot will initiate the operation • OnError: the state where the robot will end up in case of an error. <p>You have the option to edit statements (the individual commands that you are trying to execute) and add or remove states (the collections of statements). In the Available States window, select the OnInitialize state. In the Selected State window, the Initialize Control statement will be enabled.</p>  <p>The screenshot shows two windows. The 'Available States' window on the left has 'OnInitialize' highlighted with a red box. The 'Selected State' window on the right shows a list of statements: 1. Initialize Control Enable Power Home Robot (highlighted with a red box) and 2. Define Gripper Servo.</p>




Step	Action
5.	<p>To add the motion profile, under Input Arguments, go to Profile and click the three dots on its right. When the Select a Reference window pops up, select the profile from the list. Click Accept when you are finished.</p> 
6.	<p>After configuring the OnInitialize statement, edit the OnRun state. In the Available States window, select the OnRun Statement.</p> <p>NOTE: In the following steps, you will create an Auto-Teach, pick-and-place program by using the available statements. The program logic that is part of the OnRun statement will include manipulating the gripper, moving to the picture location, using the vision to locate the target, and executing the pick-and-place routine.</p> 




Step	Action				
7.	<p>To start the sequence, in the Statement Browser on the right side of the screen, click the Gripper statement and drag and drop it into the Selected State window. This will give access to manipulating the open/close state of the gripper.</p>  <p>The screenshot shows the 'Camera Display' window with a 'Selected State' pane containing '1 Gripper Open'. The 'Input Arguments' pane shows 'Mode' set to 'Open'. The 'Statement Browser' on the right lists various statements, with 'Gripper' highlighted. A red arrow points from the 'Gripper' statement in the browser to the 'Gripper Open' state in the Selected State window.</p>				
8.	<p>In the Input Arguments window, select the Open state for the gripper.</p>  <p>The screenshot shows the 'Input Arguments' pane with a table:</p> <table border="1"><thead><tr><th>Name</th><th>Value</th></tr></thead><tbody><tr><td>Mode</td><td>Open</td></tr></tbody></table> <p>The 'Open' value in the 'Value' column is highlighted with a red box. The 'Statement Browser' on the right is visible, showing the 'Gripper' statement selected.</p>	Name	Value	Mode	Open
Name	Value				
Mode	Open				
9.	<p>In the Statement Browser, drag and drop the Move statement into the Selected State window.</p>  <p>The screenshot shows the 'Selected State' pane with two items: '1 Gripper Open' and '2 Move to '(undefined location)'' (where 'undefined' is in red). The 'Input Arguments' pane shows 'Mode' set to 'Open'. The 'Statement Browser' on the right lists various statements, with 'Move' highlighted. A red arrow points from the 'Move' statement in the browser to the 'Move' statement in the Selected State window.</p>				




Step	Action
10.	<p>After adding the Move statement to the list of commands, edit the Input Arguments by adding the location and desired profile. In the mode for Move, the user has options to Move, Approach, and Move to the Location. This step is to add a Move statement and program the robot to move to the predefined picture location.</p> <p>NOTE: If a statement is not configured properly, the interface will display an exclamation mark in front of the newly added statement. After completing the required information, the exclamation mark will disappear.</p> 
11.	<p>If more settling time is required for this particular motion, enable the Wait Motion Done option. This will ensure that the robot is at the desired location before the next step in the program is executed. In this case, this is required since the picture location is where the robot will need to arrive before the vision system acquires the image for detecting the fiducial markers.</p> 
12.	<p>To detect the fiducial markers and teach the stereo location, drag and drop the Get Stereo Location statement from the Statement Browser window to the OnRun state window.</p> 



Step	Action																																				
13.	<p>It is important to fill out the Input Arguments to apply the statement correctly. The table below defines the Input Arguments.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: left;">Input Arguments</th> </tr> <tr> <th style="width: 60%;">Name</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>Location Mode</td> <td>Location</td> </tr> <tr> <td>Fiducial Mode</td> <td>Double</td> </tr> <tr> <td>Camera Number</td> <td>1</td> </tr> <tr> <td>Vision Process</td> <td>VisionProcess</td> </tr> <tr> <td>Vision Tool</td> <td>Aruco_locator</td> </tr> <tr> <td>ArUco 1</td> <td>2</td> </tr> <tr> <td>ArUco 2</td> <td>3</td> </tr> <tr> <td>Fiducial Distance</td> <td>63.00</td> </tr> <tr> <td>Settling Time</td> <td>1000</td> </tr> <tr> <td>Max ArUco Retries</td> <td>7</td> </tr> <tr> <td>Max Target Retries</td> <td>7</td> </tr> <tr> <td>Optimum Distance To Target</td> <td>150</td> </tr> <tr> <td>Precision Scale Factor</td> <td>0.50</td> </tr> <tr> <td>Error Distance</td> <td>2.00</td> </tr> <tr> <td>Offset</td> <td>offset_loc</td> </tr> <tr style="background-color: #0056b3; color: white;"> <td>Location</td> <td>result_loc</td> </tr> </tbody> </table> <p>Location Mode: This parameter configures the statement and defines if a single location or reference frame is used as a place destination after the target is located and the destination location is constructed.</p> <p>Fiducial Mode: Options for double or single ArUco mode. Use double fiducial mode for this setup</p> <p>Camera Number: Camera index 1 is the front camera and index 2 is the bottom camera.</p> <p>Vision Process: Select the preconfigured vision process that includes the tool used for detecting fiducial markers.</p> <p>Vision Tool: The tool that will be used for detecting the fiducial markers.</p> <p>Aruco 1 and Aruco 2: Contain the numeric representation of the fiducial markers. Fiducial distance is the distance between the two ArUco markers (center to center).</p> <p>Fiducial Distance: The distance between the centers of the two ArUco markers.</p> <p>Settling Time: The time between the robot arriving at the location and taking the image</p> <p>Max Aruco Retries and Max Target Retries: The maximum number of retries for the vision system to detect the fiducial markers and calculate the center point.</p> <p>Optimum Distance to Target: The distance between camera and target. Distance is specified during the robot's calibration and is given as a parameter in the form of range. The optimal distance in this section should be within the range given when the vision system was calibrated.</p> <p>Precision Scale Factor: An error tolerance parameter used to detect inaccuracies in the vision location of the ArUcos. The range of values should be between 0.1 and 1. The default value is 0.5. This can be changed to adjust the allowed error in the location process.</p> <p>Error Distance: The maximum allowed distance error between the calculated fiducial distance and the expected fiducial distance. The distance error is specified in mm. For example, if the Fiducial distance (Distance between the fiducial markers in mm - center to center) is 63mm, Error Distance of 2mm will result of total allowable measured distance of 63 +/- 2mm between the ArUco markers.</p> <p>Offset: The vision offset that was configured. It represents the position transformation between the target and the actual pick location (if applicable).</p> <p>Location The result location after the predefined offset is applied the resulting location will be the actual location used for picking the part.</p>	Input Arguments		Name	Value	Location Mode	Location	Fiducial Mode	Double	Camera Number	1	Vision Process	VisionProcess	Vision Tool	Aruco_locator	ArUco 1	2	ArUco 2	3	Fiducial Distance	63.00	Settling Time	1000	Max ArUco Retries	7	Max Target Retries	7	Optimum Distance To Target	150	Precision Scale Factor	0.50	Error Distance	2.00	Offset	offset_loc	Location	result_loc
Input Arguments																																					
Name	Value																																				
Location Mode	Location																																				
Fiducial Mode	Double																																				
Camera Number	1																																				
Vision Process	VisionProcess																																				
Vision Tool	Aruco_locator																																				
ArUco 1	2																																				
ArUco 2	3																																				
Fiducial Distance	63.00																																				
Settling Time	1000																																				
Max ArUco Retries	7																																				
Max Target Retries	7																																				
Optimum Distance To Target	150																																				
Precision Scale Factor	0.50																																				
Error Distance	2.00																																				
Offset	offset_loc																																				
Location	result_loc																																				

Step	Action
14.	After the vision system acquires the image and constructs the location by detecting the fiducial markers, the robot will need to approach and move to the newly constructed location.
15.	<p>From the statement browser, drag and drop the Move statement into the OnRun> Selected State window.</p> 
16.	<p>Edit the input arguments of the Move statement to include the result_loc in Location. This is the location where the vision system will save the newly constructed location from detecting the fiducial markers and apply the offset location that was taught in the previous section. Set the move Mode to Approach and set the Height to the desired approach distance and direction. In this case, the robot will approach the location in Tool Z at 170 mm distance from the target.</p> 
17.	<p>For this step, drag and drop the Pick statement. It combines all required operations to pick the target: approaching and moving to the target, closing the gripper, and departing from where the target was located.</p> 

Step	Action
18.	<p>The approach and depart distances and mode are defined in the Input Arguments section for the operation. Specify the location of the target. In this case it will be the result_loc that was constructed after executing the Auto-Teach routine. For this motion, use the default_profile, for the Profile, and set the approach height to 50 mm and the Approach Mode to World Z.</p> 
19.	<p>After the part is picked, the next steps will be to transfer it and place it in the destination nest. Drag and drop the Move statement to the list of commands in the Selected State window.</p> 
20.	<p>Configure the Input Arguments parameters to include the destination location. In this case, the destination Location is named place. For motion Profile, use default_profile. The Mode of operation will be Approach, the approach Height will be 75 mm, and Approach Mode will be World Z.</p> 

Step	Action
21.	<p>To complete the cycle, the last step will be to add the Place statement so the part can be transferred and placed into the destination nest. From the Statement Browser, drag and drop the Place statement into the Selected State window.</p> 
22.	<p>NOTE: Any missing information in the <i>Input arguments</i> list will be identified with an exclamation point.</p> 
23.	<p>Set the target Location to place, the Profile to default_profile, the Approach height to 25 mm, and the Approach Mode to World Z.</p> 

Step	Action
24.	<p>In the Available States window, click the OnError state to modify it. For this example, you can use the default OnError routine. In this state, the system will reinitialize (Initialize Control statement) and report if any error occurs (Report Error statement).</p> 
25.	<p>After completing all the steps for defining the pick and place routine, the final requirement is to generate the code by clicking the Generate the GPL code from the sequence gear icon in the Available States window. Generating the code is required every time changes are made in the sequence of operations.</p> 
26.	<p>After the code is generated, save it by clicking the Save icon in the GPL Projects.</p> 

Step	Action
27.	<p>Before starting the project, make sure the teach plate is located in the pick location and nothing is obstructing the motion of the robot. The nest where the plate will be placed should be empty so the robot can complete the step. Click Start to start the project.</p> 
28.	<p>Click the State Machine tab to display and review the state blocks. The active state will be colored green color if no errors are detected while the routine is active.</p> 

4. Vision Toolkit

Vision Tools perform all the runtime operations needed to acquire and process an image captured from a camera.

Each instance of a tool is:

- a vision object with a graphical front-end
- a property list for configuring the tool for operation
- a read-only list of results properties that can be used by other vision objects to create more complex machine vision and logical operations.

The graphical front-ends allow the vision tools to be positioned over a captured image and so simplify their training.

ToolKit Summary

The Vision Tools Functions table below summarizes the primary function of each of the vision tools. The Type broadly categories each tool as to whether it:

- "Acquires" an image
- "Finds" an object
- "Inspects" a region
- "Enables an LED."

Click the links in the table below to see detailed description.

Vision Tools Functions

Vision Tool	Type	Description
Acquisition Tool	Acquires	Captures an image from a camera or loads it from a disk file, and stores the image into a frame buffer.
Fiducial Locator	Finds	Searches a specified region of the image and returns the location of the detected ArUco marker. Returns the coordinates of the center and the four corners of the ArUco marker.

Vision Tool	Type	Description
Barcode Reader Tool	Inspects	Reads a variety of standard 1D and 2D barcodes and returns the barcode type and the value of the barcode.
Light Control	Enables LED	Enables, disables, and adjust the brightness levels of the integrated LEDs

Acquisition Tool

A vision tool that captures an image from a camera or loads it from a disk file, and stores the image into a frame buffer. The table below shows the Acquisition Tool Properties.

Property Name	Data Type	Range	Description
1. Identity			
Name	String	n/a	Standard Identity properties
Type	String	n/a	
3. Operation			
Camera	Integer	1 - 6	Standard Operation property
GainBlue	Single	0-12 (set to -1 if not a color camera)	These properties scale the intensity values for each of the three color layers as they are read from the camera. This permits the color intensities to be balanced.
GainGreen	Single		
GainRed	Single		
3A. Advanced Operation			
AcquireBuffer-Image	Boolean	True / False	If True, a copy of the image is stored into a secondary buffer when the image is acquired. This must be set True if the original image is to be restored by a subsequent Acquisition tool that has its AcquireMode set to "RESTORE_ORIGINAL." For resolutions greater than 640x480, setting this value to False, if not needed, can save a few milliseconds of execution time. Set False by default.

Property Name	Data Type	Range	Description
Acquire-Extension	List	BMP / PNG	If this tool is set to automatically save a camera image to a disk file, this property specifies whether the image should be saved as a non-compressed bitmap (BMP) or as a compressed image in a lossless format (PNG) or as a compressed image in a lossy format (JPG). The PNG and JPG file formats are smaller, but requires more CPU time to create.
AcquireFill-GrayLevel	Integer	0 - 255	If the AcquireMode is defined as "CLEAR_BUFFER," all of the pixels in the image buffer are set to the intensity value specified by this property.
AcquireMax-CurrentCount	Integer	0 - 99999	When the AcquireMode is set to ACQUIRE_AND_SAVE or SAVE_ONLY, the AcquireMaxSaveImages property defines the largest index that is appended to the AcquirePrefix to generate the name of the file in which the image is stored. If AcquireMaxSaveImages is -1, the next highest unused index values is assigned up to the maximum value of 99999. So, existing image files will not be over-written. If AcquireMaxSaveImages is set >0, AcquireMaxCurrentCount will indicate the next index.
AcquireMax-SaveImages	Integer	-1 - 99999	When the limit specified by AcquireMaxSaveImages is reached, AcquireMaxCurrentCount is automatically reset to 0. This permits the last AcquireMaxSaveImages files to be saved without consuming more and more disk space (but existing image files will be over-written). In this mode of operation, AcquireMaxCurrentCount can be manually changed or automatically altered by a robot control program to reset the next index to a specific value. The value of AcquireMaxCurrentCount is not stored with the vision project and is reset to 0 each time the vision project is loaded.

Property Name	Data Type	Range	Description
AcquireMode	List	NORMAL_ ACQUIRE / ACQUIRE_ AND_ SAVE / CLEAR_ BUFFER / PLAY_FROM_ DISK / LIVE_VIDEO / SAVE_ONLY / RESTORE_ ORIGINAL	<p>"NORMAL_ACQUIRE" - acquires a single image from the specified camera and places it into a frame buffer.</p> <p>"ACQUIRE_AND_SAVE" - performs the same operation as "NORMAL_ACQUIRE" and then saves the image to a disk file.</p> <p>"CLEAR_BUFFER" - Sets all of the pixels in a buffer to the intensity value specified by AcquireFillGrayLevel. This is useful before an AOI copy is performed.</p> <p>"PLAY_FROM_DISK" - restores an image from a disk file. The disk file is specified by the AcquirePath and AcquirePrefix (see below). If there are multiple numbered image files with the same prefix, each time the Vision Process is executed, the contents of the next sequential file will be copied to the image buffer.</p> <p>"LIVE_VIDEO" - continuously updates the vision display with the latest image from the camera. This is a system setup mode that facilitates setting the camera f-stop, focus, VideoGain, and VideoOffset.</p> <p>"SAVE_ONLY" - stores the contents of the current frame buffer to a disk file. This enables a GPL program to execute a vision process that saves selected frame buffers for later access.</p> <p>"RESTORE_ORIGINAL" - restores the contents of the current frame buffer to its original value at the time that the image was first captured. Requires that AcquireBufferImage is set to True when the image is first captured.</p>
AcquirePath	String	n/a	String that defines the path to the disk file when AcquireMode is set to "ACQUIRE_AND_SAVE" or "PLAY_FROM_DISK." If blank (""), the path defined in the Preferences will be used. If the path does not contain a ':' (i.e. C:\...), AcquirePath will be appended to the path where the PreciseVision application is stored, e.g. "C:\Program Files\Precise Automation\PreciseVision #.#"
AcquirePrefix	String	n/a	String that defines the disk file name (excluding the required .BMP extension) when AcquireMode is set to "ACQUIRE_AND_SAVE" or "PLAY_FROM_DISK." If blank (""), the file name defined in the Preferences will be used. This string is combined with AcquirePath , a numerical index, and the ".BMP" file extension to generate the disk file name for saving or loading vision images.

Property Name	Data Type	Range	Description
ActiveLayer	List	Monochrome / RedLayer / GreenLayer / BlueLayer	<p>Specifies the type of data to be loaded into the image frame buffer for processing by subsequent vision tools.</p> <p>For grayscale cameras, only "Monochrome" image buffers are available and each pixel in the frame buffer has a value from 0 to 255 that defines its grayscale intensity.</p> <p>For color cameras, the frame buffer can be loaded with one of four types of data: monochrome, red, green or blue. The monochrome mode produces the same results as a grayscale camera. The red, green and blue modes load the intensity data for a single color. For example, if "RedLayer" is selected, the image frame buffer will contain values that indicate the intensity (response) of only the red receptors of the camera. Tools that are applied to this image will only be operating on the red color layer of the camera. The one exception is the "Pixel Color Window" Tool. When this tool is executed, it automatically accesses all three of the RGB color layers of an image and is unaffected by the setting of the ActiveLayer property.</p>
AoiAcquire	Boolean	True / False	<p>For cameras (such as most IDS uEye USB models) that support acquiring only a portion of the full field of view, these parameters define the rectangular section of the image to be acquired. If a reduced size AOI is acquired, the camera acquisition time will be reduced. Different Acquire tools can have different sized and positioned AOI's. However, when switching between different AOI's, there is typically a significant time delay.</p> <p>To acquire an AOI, set AoiAcquire True and define the height, width and position of the AOI. The AOI dimensions and position are specified in calibrated units (mm) like most tools instead of pixels.</p>
AoiHeight	Single	0 - FOV (mm)	
AoiWidth	Single	0 - FOV (mm)	
AoiXpos	Single	0 - FOV (mm)	
AoiYpos	Single	0 - FOV (mm)	
FlatFieldEnabled	Boolean	True / False	<p>If True, each captured image is automatically compensated for uneven background lighting by adding a sample image that was previously saved. The saved image is automatically inverted and normalized such that when it is added to a new image, a very light uniform (flat) background is produced. This can make it easier to distinguish objects when there are background lighting variations, especially if binary vision tools are utilized. See below for a description of the Special Feature Buttons for capturing the sample image.</p>
ImageFile	String	n/a	<p>Read-only string that displays the currently selected vision image file. This value is only displayed when the AcquireMode is set to "PLAY_FROM_DISK."</p>

Property Name	Data Type	Range	Description
LoadFirstImage	Boolean	True / False	This is a convenience feature for setting the display of a sequence of images back to the first image and is only valid during the "PLAY_FROM_DISK" mode. That is, when this property is set to TRUE, the disk file that satisfies AcquirePath and AcquirePrefix and has the lowest index values will be loaded into the image buffer.
3B. Trigger			
TriggerActive	List	Low_to_High / High_to_Low	If TriggerEnable is True, this property defines if the picture is to be when the digital input signal transitions from low to high or high to low.
TriggerEnable	Boolean	True / False	If this property is True, the image capture is delayed until a digital input signal of the correct state is received by the camera.
TriggerTimeout	Integer	1 - 30	If TriggerEnable is True, this property specifies the time in seconds that the system will wait for the trigger to occur before an error is generated (-4019 Vision Process Failed).
4. USB Cameras			

Property Name	Data Type	Range	Description
BackLight Compensation	Integer		<p>These properties change the operation of USB cameras. The properties that a camera supports and the range of values for each property will vary from one camera model to the next and the software driver used to access the camera. When a camera is attached by PreciseVision, its supported properties, the range of allowed values and the default values are automatically sampled.</p> <p>The range for each supported property is displayed by the "Adjust Video Properties" Special Features window.</p> <p>Special attention should be paid to the Exposure and PixelClock properties since these affect the time it takes to acquire an image.</p> <p>See the documentation provided with the camera for specific information on the setup of its supported properties.</p>
Brightness	Integer		
ColorEnable	Integer		
Contrast	Integer		
Exposure	Integer		
ExposureTime	Single		
Focus	Integer		
Gain	Integer		
GainBoost	Integer		
Gamma	Integer		
Hue	Integer		
Offset	Integer		
PixelClock	Integer		
Saturation	Integer		
Sharpness	Integer		
WhiteBalance	Integer		

Property Name	Data Type	Range	Description
Zoom	Integer		

This tool performs the basic image capture operation from a color or monochrome camera and stores the image in a frame buffer. Consequently, this tool is normally the first tool in each Vision Process.

Multiple cameras can be accessed by this tool and their gains and offsets can be controlled to optimize the brightness range for the field of view. To facilitate setting up a camera's gain, offset, focus, and f-stop, the camera image can also be continuously acquired and displayed in the Camera Display Window.

Normally, when this tool is executed, a camera image is immediately captured. However, if **TriggerEnable** is True, executing this tool primes an image capture, but the picture is not immediately taken. The image capture is delayed until a digital signal, which is directly connected to the camera, is asserted. For applications where the timing of the image capture relative to an external event is critical, trigger mode can significantly reduce latency and jitter. As a debugging convenience, if a Vision Process is manually executed using the PreciseVision GUI and the process contains an **Acquisition** that has triggering enabled, a window is display to confirm if the camera should wait for an external trigger or if the picture should be taken immediately. This window is not displayed if the Vision Process is remotely initiated from a Guidance Controller.

Camera triggering is not supported on all cameras. Consult the camera's hardware documentation for specific information on whether it supports external triggering and how this is implemented.

Most vision tools analyze the data that is stored in a frame buffer by an Acquisition tool, generate results, and leave the frame buffer unmodified. However, if an "Image Process" tool is executed (e.g. a low pass filter), the data stored in the frame buffer is altered so that all subsequent tools operate on the modified image data. In these cases, it is sometimes convenient to restore the original contents of the frame buffer. This can be done by executing an Acquisition Tool with the **AcquireMode** set to "RESTORE_ORIGINAL." This operation restores the original image data from an in-memory buffer, and is therefore much faster than storing an image to a file and then reloading. In order for this mode to operate properly, the original Acquisition tool must have its **AcquireBufferImage** property set to True. When this property is true, a copy of the camera image is generated in memory when the acquisition is performed.

If the background lighting is not uniform, **FlatFieldEnabled** can be set to automatically add a previously saved inverted normalized image of the background lighting. This will produce a "flat" background that will help to highlight the features of parts within the field of view. Enabling this function adds about 1 msec of processing time to a 752x480 grayscale image. (See the Special Feature Buttons below.)

As both a demonstration feature and as an aid in remotely diagnosing problems, this tool can be used to easily store captured images to a disk file and to reload images stored to the disk. To store

images, the **AcquireMode** must be set to "ACQUIRE_AND_SAVE" or "SAVE_ONLY." To load files, the mode must be set to "PLAY_FROM_DISK." For any of these modes, the disk file name is constructed by combining the **AcquirePath** with the **AcquirePrefix** and an optional numerical index followed by the .BMP file extension. Each time that an **Acquisition Tool** is executed with "ACQUIRE_AND_SAVE" or "SAVE_ONLY" set, the system automatically increments the numerical index to create a new disk file. Likewise, each time that the **Acquisition** is executed with "PLAY_FROM_DISK," the system automatically searches the file folder for the file with the next larger numerical index. This automatic indexing allows a series of images to be conveniently generated or replayed.

Fiducial Locator

The Fiducial Locator searches a specified region of the image and returns the location of the detected ArUco marker. It returns the coordinates of the center and the four corners of the ArUco marker.


Property name	Data Type	Range	Description
Identity			
Camera number	Integer	1-2	Standard Operation properties 1 – Front facing camera 2 – Bottom facing camera
Name	String	N/A	Standard Identity properties
Placement/Size			
Height	Single	0 - AOI (mm)	These values define the height and width of the vision tool in calibrated units (mm). These values are automatically updated when the tool is adjusted with the mouse or can be manually entered for more Width Single precise adjustments.
Width	Single	0 - AOI (mm)	
X Position	Single	0 - AOI (mm)	Position (in calibrated units, mm) of the center of the vision tool in the coordinates of the vision image. These values are automatically updated when the tool is graphically repositioned and re-oriented during training and if the vision tool is placed relative to another vision tool during runtime.
Y Position	Single	0 - AOI (mm)	
Operation			

Property name	Data Type	Range	Description
Adaptive Threshold	Integer	1-100	Constant for adaptive thresholding before finding contours.
Corner Max Iterations	Integer	1-n	Maximum number of iterations for stop criteria of the corner refinement process (default 30). If the number of iterations is too high, it may affect the performance. On the other hand, if it is too low, it can result in poor sub-pixel refinement.
Corner Min Accuracy	Double	0.001-n	Minimum error for the stop criteria of the corner refinement process (default: 0.1)
Corner Refinement	List	None/SubPixel/Contour	The corner refinement method. SubPixel - refine the corners locations using corner subpixel accuracy. Contour - refine the corners locations using the contour-points line fitting.
Corner Window Size	Integer	1-n	Window size for the corner refinement process (in pixels) (default 5). This parameter determines the maximum window size for the corner refinement process. High values can cause close corners of the image to be included in the window area, so that the corner of the marker moves to a different and incorrect location during the process. Also, it may affect performance.
Dictionary	List	Dict4X4_250 / Dict5X5_250 / Dict6X6_250 / Dict7X7_250 / Dict7X7_1000	The ArUco marker dictionary configuration to use when executing the algorithm. The dictionary specifies the size and the codification of the markers. The dictionary might be defined to have markers that are 5x5 bits, meaning each marker is a 5x5 grid where each cell can be black or white. The dictionary defines which patterns of black and white cells correspond to which marker IDs.
Relative Tool	String	N/A	
Results Settings			
Result Color	List	Gold / Blue / Violet / Red / Black / White	The color to use when rendering the result markers on the screen
Result Scale	Double	0-n	The scale for the size of the result

Property name	Data Type	Range	Description
Show Results	List	NONE / POINT / LINE / FRAME / ARC	Alters how the results of a tool are graphically displayed. Each vision tool has a default method for display, e.g. a line or a frame. This property allows the graphical display to be changed. For example, a Fixed Frame Tool is normally displayed as a reference frame. However, if it is being used as a datum line or a point, its display can be changed to a line or a point for visual clarity. This property does not affect the actual results of the tool.

Barcode Reader Tool

A Vision tool that reads a variety of standard 1-D and 2-D barcodes and returns the barcode type and the value of the barcode.



Barcode Reader Tool

Property Name	Data Type	Range	Description
1. Identity			
Name	String	n/a	Standard Identity properties
Type	String	n/a	
2. Placement/Size			

Property Name	Data Type	Range	Description
Angle	Single	0 (<i>non-rotating</i>)	Standard Placement/Size properties. The X and Y values define the center of the region to be analyzed. The Height and Width define the dimensions of the region. The AOI cannot be rotated, but rotated barcodes can be identified (see SkewTolerance).
Height	Single	0 - AOI (mm)	
Width	Single	0 - AOI (mm)	
XPos	Single	0 - AOI (mm)	
YPos	Single	0 - AOI (mm)	
RelAngle	Single	0	
RelXPos	Single	0 - AOI (mm)	
RelYPos	Single	0 - AOI (mm)	
3. Operation			
Camera	Integer	1 - 6	Standard Operation properties
Relative-ToolName	List	n/a	
ProcessLevel	Integer	0 - 5	Controls the speed with which regions are processed verses accuracy. A lower value will process images more quickly but will result in a lower successful read-rate. The default value is 2.

Property Name	Data Type	Range	Description
SkewLineJump	Integer	1 - 9	<p>In order to recognize barcodes that are not aligned along the horizontal or vertical axes of the camera, the SkewTolerance and SkewLineJump must be adjusted. The approximate permitted angular deviations of a barcode from a horizontal or vertical orientation for various settings of the SkewTolerance are as follows:</p> <p>0 - up to 5 degrees 1 - " " 13 " 2 - " " 21 " 3 - " " 29 " 4 - " " 37 " 5 - " " 45 "</p>
SkewTolerance	Integer	0 - 5	<p>The SkewLineJump determines how many lines are skipped during the portion of the scanning process that is specifically for locating skewed barcodes. 1 means that every line in the region is tested. Lower values for this parameter will increase the processing time but may be useful for poor quality images.</p> <p>If the barcode is aligned along the X or Y axes, the SkewTolerance should be set to 0 and the SkewLineJump should be set to 9 to minimize the tool's processing time.</p>
3A. Advanced Operation			
AllowDuplicates	Boolean	TRUE / FALSE	If a barcode is badly damaged, the same barcode maybe reported twice within the same image. If this parameter is FALSE, duplicate results are only reported a single time. If TRUE, the same value can be returned multiple times in the same image.
Bottom_To_Top	Boolean	TRUE / FALSE	<p>These parameters specify the directions in which the software will scan looking for barcodes. If the barcodes always appear in the same orientation, turning off the unneeded scanning directions will reduce execution time. Also, see SkewTolerance for the ability to identify barcodes that are not oriented vertically or horizontally.</p>
Left_To_Right	Boolean	TRUE / FALSE	
Right_To_Left	Boolean	TRUE / FALSE	
Top_To_Bottom	Boolean	TRUE / FALSE	
5. Results Settings			

Property Name	Data Type	Range	Description
MaxResults	Integer	-1 or 1 to n	Standard Results Settings properties
ResultOnNotFound	Boolean	TRUE / FALSE	
ShowResults	List	NONE / FRAME / LINE / POINT	
ShowResultType	Boolean	TRUE / FALSE	If ShowResultValue is TRUE, the identified barcode value will be displayed on top of the barcode in the camera window. In addition, if ShowResultType is TRUE, the display will include the type of the barcode that was found.
ShowResultValue	Boolean	TRUE / FALSE	
6. Results			
ResultErrorCode	Integer		Standard Results properties X and Y position represent the centroid of the located barcode.
ResultAngle	Single	0 (non-rotating)	
ResultXPos	Single	mm	
ResultYPos	Single	mm	
ResultCode	String		The type of the barcode, e.g. UPCA. [GPL: <i>VisResult.InfoString</i>]
ResultCodeDirection	Integer		Indicates the scanning direction used to locate the barcode [GPL: <i>VisResult.Info(1)</i>] 1 - Left to right 2 - Bottom to top 4 - Right to left 8 - Bottom to top
ResultCodeValue	String		The value of the barcode. [GPL: <i>VisResult.InfoString</i>]

This tool reads a variety of popular types of 1-D and 2-D barcodes. More than one barcode can be located within a single AOI and the barcodes can be of different types (although searching for multiple types of barcodes increases execution time). The value of the barcode as well as its type are returned by this tool and can optionally be displayed in the camera window on top of the identified barcode.

This tool can locate barcodes that are oriented in any direction (although barcodes that are approximately horizontal or vertical are processed most quickly). This tool will operate on grayscale or color images, with grayscale images being processed more rapidly and more reliably due to the single image plane and higher quality edges.

In order to reliably detect barcodes and to determine their correct values, the following should be kept in mind:

- As a general rule-of-thumb, the thinnest bar should be at least 3 pixels wide. Likewise, the smallest gap between bars should be at least 3 pixels wide.
- If a barcode is not horizontal or vertical but is tilted (skewed), the minimum bar and gap width should be increased to at least 5 pixels since diagonal lines look like stair steps and alternately are thick and thin.
- Even if the barcode's position is well known, white space should be included in the AOI around the barcode so that the software can detect the start and end of the bars or squares.

The Barcode Reader Tool can detect a number of different codes and can correctly operate even when the barcode is at any orientation or the image is somewhat degraded or the barcode is slightly defective. However, the execution speed of this tool can be optimized by reducing the generality of the property settings, such as reducing the size of the AOI to be searched, disabling unneeded barcode types, reducing the skew tolerance, etc.

Special Feature Buttons (located above the property editor)

Select Codes

Clicking this button displays a window that can restrict the types of barcodes that are detected during the scanning process. Disabling unneeded types will reduce the execution time of the tool. Currently, variations of the following types of 1-D and 2-D barcodes can be detected: *Code 39*, *Code 93*, *Code 128*, *Code 25 (interleaved and non-interleaved)*, *Codabar*, *EAN-8*, *EAN-13*, *UPC-A*, *UPC-E*, *PDF-417*, *Data Matrix*, *Databar*, and *Patch Codes*.

Advanced Settings

Clicking this button displays a window that presents more advanced properties of the barcode tool whose default values are normally acceptable. For convenience, this window also contains duplicates for some of the common properties that are contained on the standard Property Display. The table below describes the operation of the unique Advanced Settings.

Advanced Settings

Property Name	Data Type	Range	Description
Convert UPC-E to EAN-13	Boolean	TRUE / FALSE	If TRUE, UPC-E barcodes are automatically converted into EAN-13. This is FALSE by default.

Property Name	Data Type	Range	Description
GammaCorrection	Integer	1 - n	If this value is not 100, a Gamma Correction equal to GammaCorrection /100 will be applied to adjust the overall illumination of the AOI. By default, this value is 100, which means don't apply a correction.
Line Jump	Integer	1 - 9	This property determines how many lines are skipped during the initial scan for a barcode. 1 means that every line in the region is tested. Lower values for this parameter will increase the processing time but may be useful for poor quality images. This value is 1 by default.
Median Filter	Boolean	TRUE / FALSE	If TRUE a median filter is applied to the AOI before scanning for the barcode. This can eliminate small flaws in high resolution images. It should not be applied to low resolution images since this will blur the transitions between bars and gaps. This is FALSE by default.
Max Length	Integer	1 - 999	Specifies the largest number of characters in the barcode including any checksum characters. Set to 999 by default.
Min Length	Integer	1 - 999	Defines the minimum acceptable number of characters in a valid barcode value. Set to 4 by default.
Min Space Width	Integer	0 - n	Defines the minimum acceptable width of spaces between bars. Spaces that are smaller than this size are ignored. By default, this value is 0, which implies that the system will automatically determine the minimum acceptable width.
Noise Reduction	Integer	0 - n	If greater than 0, the AOI is filtered before being scanned to eliminate marks that are unlikely to be part of the barcode. Larger values will reduce larger marks. This can be helpful in poor quality images. A typical value is 10. By default, this is set to 0.
Numeric Barcode	Boolean	TRUE / FALSE	If TRUE, only numeric barcodes are identified. By default, this value is FALSE.
Quiet Zone	Integer	0 - n	When a line in the image is scanned, regions that are not preceded by this number of white pixels are ignored. Set to 0 by default.
Show Check Digits	Boolean	TRUE / FALSE	If TRUE, the barcode check digit will be included in the barcode value. This property only applies to barcode types with built-in check digits, such as Code 128. Set FALSE by default.
Use Oversampling	Boolean	TRUE / FALSE	If TRUE, 3 sequential lines at a time are scanned and their average pixel value is used to determine the barcode. This is useful for images that contain both white and black speckles. Set FALSE by default.

Examples

The following two examples demonstrate the Barcode Reader Tool identifying the same character pattern presented as both a 1-D Code 39 and a 2-D Data Matrix pattern. In and , the darker blue boxes display the barcode type and value as determined by this tool.



Barcode Type and Value



Barcode Type and Value

Light Control

Light Control enables, disables, and adjust the brightness levels of the integrated LEDs.

Property Name	Data Type	Range	Description
1. Identity			
Camera number	Integer	1-2	Standard Operation properties 1 – Front facing camera 2 – Bottom facing camera
Name	String	N/A	Standard Identity properties
3. Operation			

Property Name	Data Type	Range	Description
Brightness %	Integer	0-100	Integrated light brightness level. 0 – disabled 100 – highest brightness level
LED Bank	Integer	1-2	Integrated light source selection 1. Front facing light source 2. Bottom facing light source
Time Delay (ms)	Integer	0-n	Delay for executing the light control tool in ms.

5. Camera Calibration

Stereoscopic Calibration

The IntelliGuide Vision Gripper is installed and calibrated from the factory. The only time it should need recalibration is when you replace the IntelliGuide Vision Gripper, remove its cover, or after major software updates. This chapter covers IntelliGuide Vision Gripper calibration.



Stereoscopic calibration is a process where multiple images of the calibration target are acquired, and calculations are performed to create the calibration model. The defined calibration model is used by the vision system to define location in space (X,Y,Z, and Yaw) after detecting fiducial markers (ArUco). The defined location in space can be used for picking targets, auto teaching routines, creating offsets etc.

For proper functionality of the IntelliGuide Vision Gripper, you must perform a stereoscopic calibration for each camera. The calibration is unique for each camera, and it cannot be transferred to another camera. That means that if the calibration model is lost, you must execute the routine again.

Requirements:

- Fully calibrated robot
- Installed IntelliGuide Vision Gripper with properly adjusted focal length.
- Preferable if the robot homing procedure is already executed.
- The robot is mounted on a surface where no other devices or machinery is causing vibration that can be transferred to the arm or the calibration board.
- Loaded vision project used specifically for stereoscopic camera calibration.
- The assumption is that all required licenses are installed.

NOTE: Brooks recommends that the light source is consistent and the vision process is tested before starting the calibration.


 CAUTION Robot Movement	
<p>During the stereoscopic camera calibration, the robot will automatically move to locations. It's important to position the robot properly before the process is started, and ensure nothing is obstructing the robot's motion during the calibration process.</p>	



Before starting the calibration procedure, make sure the robot and the vision system are accessible and connection can be established.



You must create or use existing vision projects that include vision processes with the image [Acquisition Tool](#) and [Fiducial Locator](#) tools configured as part of the vision process. If no vision project is available, the user can follow the steps for creating vision project described in the document earlier.


For successful execution of the stereoscopic calibration routine, use the ArUco calibration board provided by Brooks.




To execute a stereoscopic calibration routine, perform the following steps.

Step	Action
1.	<p>From the main toolbar, open the Vision drop-down menu and select Stereoscopic Arm Camera to initialize the wizard</p>  <p>The screenshot shows the software interface with the 'Vision' menu open. The menu items include: Show Vision Toolbar, Vision Project, Cameras, Tool Properties, Camera Configuration, Vision License, Classifier Models, Pixel Calibration, Clear Pixel Calibration, Arm Mounted Camera, Fixed Mounted Camera, Upward Facing Camera, and Stereoscopic Arm Camera. The 'Stereoscopic Arm Camera' option is highlighted in blue.</p>


Step	Action
2.	<p>In the popup window, select the camera to be calibrated and click Accept. For this example, calibrate camera 1, which is the front-facing camera.</p> 
3.	<p>It is important to properly position the robot and calibration board. Start by bending the robot's arm into a <i>righty</i> configuration.</p> 




Step	Action
4.	<p>If the front camera is being calibrated, place the ArUco board in front of the robot. The ArUco number 0 should be in the top-left corner when viewed from the camera's perspective. Place the arm so the camera is facing the center of the ArUco board at approximately 0.5 to 1 inches/ 12.7 to 25.4 mm from the end of the gripper fingers.</p> 
5.	<p>For the bottom camera, the ArUco number 0 should be in the far-left corner under the camera. When calibrating the bottom camera, place the robot arm so the camera is approximately 1 inch/ 25.4 mm above the center of the calibration board</p> 

Step	Action
6.	<p>When positioning the arm, make sure all four corners of the board are accessible and the robot can reach all of them. The camera must have clear views of the ArUco markers located in the corners of the board. This instruction is described in detail in the wizard window.</p> <p>If you are required to jog the robot to position the arm properly, click the Pendant button to access the virtual jog pendant. You can manipulate the power state from the Enable/Disable buttons.</p> <p>When all the conditions are met, click Next.</p> <div data-bbox="326 537 1330 1304" style="border: 1px solid gray; padding: 10px;"> <p>Please locate your calibration target. You will need to place the calibration board in the work cell and align the robot starting position similar to the picture below. Make sure to orient the calibration board so the first aruco, highlighted in yellow, is presented to the robot in the proper position. In addition, you will need to select a vision process configured to locate the calibration target.</p>  <div style="display: flex; justify-content: space-around; margin-top: 10px;"> Enable Disable Pendant Previous Next </div> </div>
7.	<p>Click Initialize to initialize the vision system. This will load the required system files into the controller memory. After the system files are loaded, the Next button will be active. Click Next.</p> <div data-bbox="326 1436 1240 1814" style="border: 1px solid gray; padding: 10px;"> <div style="border: 1px solid gray; padding: 5px; margin-bottom: 10px;"> <p>Connect To Controller</p> <p>Connect to the controller to allow automatic robot motions during calibration</p> </div> <div style="display: flex;"> <div style="border: 1px solid gray; padding: 5px; width: 20%; margin-right: 10px;"> <p>Physical Setup</p> <ul style="list-style-type: none"> ➔ Connect Controller Select Vision Tool Select Options Picture Position Auto Calibrate Process Complete </div> <div style="border: 1px solid gray; padding: 5px; flex-grow: 1;"> <p>If not already connected, enter the IP address of the robot controller. Press 'Initialize' to initialize the calibration projects on the controller</p> <p>192.168.0.1 Initialize</p> </div> </div> <div style="display: flex; justify-content: space-between; margin-top: 10px;"> Cancel Enable Disable Pendant Previous Next </div> </div>

Step	Action
8.	<p>In the Select Vision Tool step, the proper vision project must be loaded. The vision project must contain vision processes that includes Image Acquisition and Fiducial vision tools. Test the process before starting the calibration procedure. The Fiducial tool for the calibration process should be configured as show below.</p> <p>In the Vision Tool drop-down menu, select Fiducial Locator.</p> 
9.	<p>In Select Desired Options, configure all required options for performing the vision calibration.</p> <p>NOTE: This is a critical step. Be careful to configure the parameters properly.</p> 
10.	<p>Gripper Properties</p> <ul style="list-style-type: none"> • Use Servo Gripper - by default the IntelliGuide Gripper is a servo gripper type. • Servo Open Position – the position where the gripper fingers are considered open. You can either input numbers to tell the system the open position for the gripper, or you can click Record to save the current position of the gripper. 

Step	Action
<p>11.</p>	<p>Calibration Board Properties:</p> <ul style="list-style-type: none"> • Board Type drop-down menu. Based on the type of board you select, some of the parameters will be populated automatically. You have the option to select Custom Board and all information related to number of Fiducial Rows and Fiducial Columns. ArUco distance (Fiducial center-to-center distance) and Fiducial Square size will need to be populated. • Minimum Optimal Distance to Target and Maximum Optimal Distance to Target are the distances from the camera of the IntelliGuide Vision Gripper to the target. Note that from the factory, the focal length and the optimal distance are configured at 150 mm. • Minimum Target Clearance is the distance from the front plate of the gripper to the end of the gripper (this parameter ensures that the gripper's fingers will not collide with any objects when the vision system is performing Auto-Teach). <div data-bbox="324 688 1143 1079" style="border: 1px solid black; padding: 5px;"> <p>Calibration Board Properties</p> <p>Board Type Large High-Res (11 x 17) ▾</p> <p>Number of Fiducial Rows <input type="text" value="18"/></p> <p>Number of Fiducial Columns <input type="text" value="28"/></p> <p>Fiducial center-to-center distance (mm) <input type="text" value="15.50"/></p> <p>Fiducial Square Size (mm) <input type="text" value="12.50"/></p> <p>Minimum Optimal Distance to Target (mm) <input type="text" value="140"/></p> <p>Maximum Optimal Distance to Target (mm) <input type="text" value="160"/></p> <p><i>The minimum and maximum optimal distance define the distance (from camera to the fiducial) over which model will provide the best position estimation. Typically this will be set to 150 - 190. These values will change if camera focal length is adjusted.</i></p> <p>Minimum Target Clearance (mm) <input type="text" value="90"/></p> <p><i>For forward facing camera this should be the distance from front face plate to end of gripper. For bottom camera this should be 0 - unless the gripper is facing downward.</i></p> </div>
<p>12.</p>	<p>Advanced Properties:</p> <ul style="list-style-type: none"> • Joints to free – in the wizard, some of the steps require you to free the joints and move the robot manually. You have the option to specify which joint should be put in free mode. By default all the joints are selected. • Extra Settling Time – this is the time that the robot will wait to completely settle during the Auto-Teach routine. In this step, you have the option to reduce or increase the settling time. By default, the time is set to 1 second. <div data-bbox="324 1394 1136 1482" style="border: 1px solid black; padding: 5px;"> <p>Advanced Properties</p> <p>Joints to free: <input checked="" type="checkbox"/> Jt1 <input checked="" type="checkbox"/> Jt2 <input checked="" type="checkbox"/> Jt3 <input checked="" type="checkbox"/> Jt4 <input checked="" type="checkbox"/> Jt5 <input checked="" type="checkbox"/> Jt6</p> <p>Extra Settling Time (ms) <input type="text" value="1000"/></p> </div> <p>When all settings are updated, click Next.</p>

Step	Action																		
13.	<p>For Teach the Picture Position, make sure the robot arm is positioned so that the camera is pointing in the middle of the calibration board and the distance from the camera plate to the calibration target is 0.5 - 1 inch/12.7 to 25.4 mm if no fingers are installed. If gripper fingers are installed, the distance between the edge of the fingers to the calibration target should be 0.5 - 1 inch/12.7 to 25.4 mm.</p> <div data-bbox="326 422 1333 1119" style="border: 1px solid gray; padding: 5px;"> <p>Teach the Picture Position</p> <p>Teach the picture position the robot will use in the process</p> <div style="display: flex; justify-content: space-between;"> <div style="width: 25%; border: 1px solid gray; padding: 5px;"> <p>Physical Setup</p> <p>Connect Controller</p> <p>Select Vision Tool</p> <p>Select Options</p> <p>→ Picture Position</p> <p>Auto Calibrate</p> <p>Process Complete</p> </div> <div style="width: 75%; border: 1px solid gray; padding: 5px;"> <p>Record the picture position the robot will use in the process. The robot should be pointing in the middle of the calibration board. You can use the 'Locate' button to make sure the target can be located at the picture position. Press 'Record' to define the picture position.</p>  <table border="1" style="width: 100%; border-collapse: collapse; margin-top: 10px;"> <thead> <tr> <th></th> <th>X</th> <th>Y</th> <th>Z</th> <th>Yaw</th> <th>Pitch</th> <th>Roll</th> <th>Lock Joints</th> <th>Free Joints</th> </tr> </thead> <tbody> <tr> <td>Current Position:</td> <td>-523.320</td> <td>259.569</td> <td>142.860</td> <td>99.267</td> <td>90.000</td> <td>180.000</td> <td>Record</td> <td>Move</td> </tr> </tbody> </table> </div> </div> </div>		X	Y	Z	Yaw	Pitch	Roll	Lock Joints	Free Joints	Current Position:	-523.320	259.569	142.860	99.267	90.000	180.000	Record	Move
	X	Y	Z	Yaw	Pitch	Roll	Lock Joints	Free Joints											
Current Position:	-523.320	259.569	142.860	99.267	90.000	180.000	Record	Move											
14.	<p>To manually move the arm, click Free Joints to free the joints, and after the arm is placed in the correct location, click Lock Joints lock the arm into position.</p> <p>After the arm is correctly placed and joints are locked, click Locate to take a picture and confirm that the calibration target is visible. When the arm is placed close to the calibration target, it is possible the image will look blurry. This is expected, and during the calibration routine, the arm will automatically move away to take multiple images.</p> <p>After the arm is positioned and a picture is taken, click Record to save the location. Click Move to position the robot in the recorded picture location.</p> <div data-bbox="326 1482 1256 1602" style="border: 1px solid gray; padding: 5px; margin-top: 10px;"> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th></th> <th>X</th> <th>Y</th> <th>Z</th> <th>Yaw</th> <th>Pitch</th> <th>Roll</th> <th>Lock Joints</th> <th>Free Joints</th> </tr> </thead> <tbody> <tr> <td>Current Position:</td> <td>-523.320</td> <td>259.569</td> <td>142.860</td> <td>99.267</td> <td>90.000</td> <td>180.000</td> <td>Record</td> <td>Move</td> </tr> </tbody> </table> <p style="text-align: right; margin-top: 5px;">Locate</p> </div>		X	Y	Z	Yaw	Pitch	Roll	Lock Joints	Free Joints	Current Position:	-523.320	259.569	142.860	99.267	90.000	180.000	Record	Move
	X	Y	Z	Yaw	Pitch	Roll	Lock Joints	Free Joints											
Current Position:	-523.320	259.569	142.860	99.267	90.000	180.000	Record	Move											

Step	Action
16.	<p>In Perform the Stereoscopic Calibration, click Calibrate in the lower right corner.</p> <div data-bbox="326 331 1386 653"> <p>CAUTION Robot and Calibration Target Movement</p> <p>During stereoscopic camera calibration, the robot will automatically move to locations close to the four corners of the calibration target. Do not obstruct robot motion.</p> <p>Do not move the calibration target.</p>  </div> <div data-bbox="326 684 1334 1386"> <p>Perform Stereoscopic Calibration Press the 'Calibrate' button to initiate the calibration process</p> <p>Physical Setup Connect Controller Select Vision Tool Select Options Picture Position Auto Calibrate Process Complete</p> <p>When ready, press the 'Calibrate' button to initiate the calibration process. The robot will automatically move around the calibration target in the field of view to collect the calibration data points.</p>  <p>Mouse Position: 2311.02, 2222.66 mm MM/Pixel: 1.000</p> <p>Speed Calibrate</p> </div>
17.	<p>The speed of the motion during the calibration routine can be adjusted by moving the Speed slider. By default, the speed is set to 50%.</p> <div data-bbox="326 1520 951 1682">  <p>Speed Calibrate</p> </div>
18.	<p>The calibration process will take approximately 15-20 minutes.</p> <p>The process for calibrating the bottom camera is the same as calibrating the front camera. The difference is in the placement of the calibration board.</p>

6. Appendices

Appendix A: Specifications




Cameras	Forward looking and downward looking
Weight	IntelliGuide v23 - 1.476 lbs (669.5 g) IntelliGuide v60 - 2.354 lbs (1067.76 g)
Resolution	SMP, H:2592, V:1944
Pixel Size	H:1.4 μ , V:1.4 μ
Lens	6 mm Manual adjustment require recalibration
Working Distance	150 mm (as configured)
Focal Length	2.8 mm
FOV (H):	72°
Lighting	PWM-controlled LED lighting
Precision, Typical from Static Position at Working Distance	± 0.18 mm in X/Y/Z, $\pm 0.19^\circ$ in rotation. (Results can vary with application)
Barcode Formats 1D	Code39 (standard and extended) Code128 (standard and short) Code25 (ITF) Codebar (Codabar) EAN_8 EAN_13 UPC_E UPC_A Code39Checksum Code39StartStop Code25Checksum Code93
Barcode Formats 2D	PDF_417 (standard and Micro) DATA_MATRIX DATABAR PATCH_CODES Aztec QR Code
Software	Programming via Guidance Development Suite (GDS) Compatible with Guidance Programming Language (GPL) Compatible with TCP Command Server

Appendix B: VSUtilities

Installing GDS and Confirming Its Version


"VSUtilities" is an executable file that uses PowerShell commands to perform remote operations on the grippers, such as IP address changes and updating software. In order to use the VSUtilities, make sure the matching version of GDS is installed on your computer.



Perform the following procedure.

Step	Action
1.	Download "GDSInstaller_[version number].zip" from the Brooks website, https://www.brooks.com/support/brooks-preciseflex-support/software-updates/
2.	<p>Double-click "GDSInstaller_[version number].zip" to extract GDS software, then double-click "PreciseGDSUI_setup[version number].exe" to install it.</p> 
3.	<p>After the installation is completed, open GDS, and confirm that the version of the executable file and the software version displayed in the title bar are the same.</p> 
4.	<p>Within the program installation path (For example: C:\Program Files\Precise GDS UI 5.0), locate the "VSUtility.exe" file to confirm the completed installation.</p> 

Changing the IntelliGuide Vision Gripper IP Address

To change the IntelliGuide Vision Gripper IP Address, execute the VSUtility.exe via the Windows Command prompt. Perform the following procedure.



Step	Action
1.	Make sure your computer has an IP Address compatible with the robot and IntelliGuide. <i>NOTE: For IP address compatibility, consult the controller manual that applies to your robot.</i>
2.	At the bottom of the screen, bring up the Command Prompt via Start > Windows Systems > Command Prompt .
3.	Navigate to the folder containing VSUtilities.exe (Use “cd” command to change directories).  <pre> Command Prompt C:\Program Files\Precise GDS UI 5.0>VSUtility.exe /help -remote -address { -subnet -gateway } -install -help Command line help -h -? /help -remote (*) The IP address of the remote system -address The new IP address to update the remote system -subnet The new subnet address for the remote system. 255.255.255.0 if not specified -gateway The new subnet address for the remote system. 192.168.0.1 if not specified -install Install the specified file on the remote vision server (*) Required C:\Program Files\Precise GDS UI 5.0> </pre>

Step	Action
4.	<p>Enter VSUtility.exe -remote CurrentAddress -address TargetAddress where:</p> <ul style="list-style-type: none"> • CurrentAddress is the current IPv4 Address of the IntelliGuide • TargetAddress is the IPv4 Address that you would like to update the IntelliGuide to.  <pre> C:\Program Files>cd Precise GDS UI 5.1 C:\Program Files\Precise GDS UI 5.1>VSUtility.exe -remote 192.168.0.200 -address 192.168.0.15 Output: Starting netsh on 192.168.0.200...192.168.0.200... netsh started on 192.168.0.200 with process ID 1056. Output: Starting net on 192.168.0.15...on 192.168.0.15... net started on 192.168.0.15 with process ID 5692. Output: Starting net on 192.168.0.15...on 192.168.0.15... net started on 192.168.0.15 with process ID 6184. </pre>
5.	<p>When the process is finished, ping the IP address to confirm connectivity.</p>  <pre> C:\Program Files\Precise GDS UI 5.1>ping 192.168.0.15 Pinging 192.168.0.15 with 32 bytes of data: Reply from 192.168.0.15: bytes=32 time=3ms TTL=128 Reply from 192.168.0.15: bytes=32 time=1ms TTL=128 Reply from 192.168.0.15: bytes=32 time=1ms TTL=128 Reply from 192.168.0.15: bytes=32 time=1ms TTL=128 Ping statistics for 192.168.0.15: Packets: Sent = 4, Received = 4, Lost = 0 (0% loss), Approximate round trip times in milli-seconds: Minimum = 1ms, Maximum = 3ms, Average = 1ms C:\Program Files\Precise GDS UI 5.1> </pre>

Updating IntelliGuide Vision Gripper Software

To update IntelliGuide Vision Gripper software, perform the following procedure.

Step	Action
1.	<p>Download "VisionInstallers_(version number).zip" from the Brooks website, https://www.brooks.com/support/brooks-preciseflex-support/software-updates/.</p>

Step	Action
2.	Click on "VisionInstallers_(version number).zip" to extract the contents.
3.	<p>Copy the extracted files into the folder C:\Vision. Create the folder on your C: drive if it doesn't already exist.</p> 
4.	At the bottom of the screen, type "Command Prompt" into the Windows Search field.
5.	Navigate to the folder containing "VSUtility.exe."
6.	<p>Enter VSUtility.exe -remote VisionGripperIpAddress -install PreciseVisionEngineServicePath where:</p> <ul style="list-style-type: none"> "IntelliGuideIpAddress" is the Current IP Address of the IntelliGuide "PreciseVisionEngineServicePath" is the path to the Precise Vision Engine Service Setup Executable (For example: C:\Vision\PreciseVisionEngine_Service_Setup_5.0.3.1.exe)
7.	<p>Wait for the program to return "Exited with error code 0."</p> 
8.	<p>Check GDS to make sure that the Remote Vision Engine Version is updated and correct after connecting to IntelliGuide.</p> 